

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-3	9541M89P01	Bearing	None
CFMI	CFM56-3	9725M84P05	Bearing	None
CFMI	CFM56-3	9725M84P06	Bearing	None
CFMI	CFM56-3	9725M84P08	Bearing	None
CFMI	CFM56-3	9725M84P09	Bearing	None
CFMI	CFM56-3	9972M33P02	Bearing	None
CFMI	CFM56-3	9972M33P08	Bearing	None
CFMI	CFM56-3	9972M34P01	Bearing	None
CFMI	CFM56-3	9972M34P02	Bearing	None
CFMI	CFM56-3	9972M34P08	Bearing	None
CFMI	CFM56-3	9972M34P09	Bearing	None
CFMI	CFM56-3	9972M34P10	Bearing	None
CFMI	CFM56-3	305-088-001-0	Bearing	None
CFMI	CFM56-3	305-128-901-0	Bearing	None
CFMI	CFM56-3	305-128-902-0	Bearing	None
CFMI	CFM56-3	305-128-903-0	Bearing	None
CFMI	CFM56-3	305-128-904-0	Bearing	None
CFMI	CFM56-3	335-304-101-0	Bearing	None
CFMI	CFM56-3	335-304-102-0	Bearing	None
CFMI	CFM56-3	335-304-103-0	Bearing	None
CFMI	CFM56-3	335-304-201-0	Bearing	None
CFMI	CFM56-3	335-304-202-0	Bearing	None
CFMI	CFM56-3	335-304-203-0	Bearing	None
CFMI	CFM56-3	335-304-601-0	Bearing	None
CFMI	CFM56-3	335-304-602-0	Bearing	None
CFMI	CFM56-3	335-304-603-0	Bearing	None
CFMI	CFM56-3	335-304-701-0	Bearing	None
CFMI	CFM56-3	335-304-702-0	Bearing	None
CFMI	CFM56-3	335-304-703-0	Bearing	None
CFMI	CFM56-3	340-052-502-0	Bearing	None
CFMI	CFM56-3	340-056-401-0	Bearing	None
CFMI	CFM56-3	301-480-320-0	Bearing	None
CFMI	CFM56-3	301-480-323-0	Bearing	None
CFMI	CFM56-3	301-480-325-0	Bearing	None
CFMI	CFM56-3	301-480-326-0	Bearing	None
CFMI	CFM56-3	301-480-720-0	Bearing	None
CFMI	CFM56-3	301-480-723-0	Bearing	None
CFMI	CFM56-3	301-480-724-0	Bearing	None
CFMI	CFM56-3	301-480-726-0	Bearing	None
CFMI	CFM56-3	301-480-920-0	Bearing	None
CFMI	CFM56-3	301-480-923-0	Bearing	None
CFMI	CFM56-3	301-480-924-0	Bearing	None
CFMI	CFM56-3	301-480-926-0	Bearing	None
CFMI	CFM56-3	305-115-100-0	Bearing	None
CFMI	CFM56-3	305-115-101-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-3	305-115-103-0	Bearing	None
CFMI	CFM56-3	305-115-104-0	Bearing	None
CFMI	CFM56-3	305-115-200-0	Bearing	None
CFMI	CFM56-3	305-115-201-0	Bearing	None
CFMI	CFM56-3	305-115-205-0	Bearing	None
CFMI	CFM56-3	305-115-300-0	Bearing	None
CFMI	CFM56-3	305-115-303-0	Bearing	None
CFMI	CFM56-3	305-115-305-0	Bearing	None
CFMI	CFM56-3	305-115-306-0	Bearing	None
CFMI	CFM56-3	335-304-401-0	Bearing	None
CFMI	CFM56-3	335-304-402-0	Bearing	None
CFMI	CFM56-3	335-304-403-0	Bearing	None
CFMI	CFM56-3	335-304-501-0	Bearing	None
CFMI	CFM56-3	335-304-502-0	Bearing	None
CFMI	CFM56-3	335-304-503-0	Bearing	None
CFMI	CFM56-3	335-304-901-0	Bearing	None
CFMI	CFM56-3	335-304-902-0	Bearing	None
CFMI	CFM56-3	335-304-903-0	Bearing	None
CFMI	CFM56-3	340-052-602-0	Bearing	None
CFMI	CFM56-3	340-054-502-0	Bearing	None
CFMI	CFM56-3	340-055-801-0	Bearing	None
CFMI	CFM56-3	340-055-901-0	Bearing	None
CFMI	CFM56-3	340-056-101-0	Bearing	None
CFMI	CFM56-3	340-056-201-0	Bearing	None
CFMI	CFM56-3	305-364-002-0	No. 1 Bearing	None
CFMI	CFM56-3	305-364-102-0	No. 1 Bearing	None
CFMI	CFM56-3	305-364-103-0	No. 1 Bearing	None
CFMI	CFM56-3	337-108-201-0	No. 1 Bearing	None
CFMI	CFM56-3	305-365-702-0	No. 2 Bearing	None
CFMI	CFM56-3	305-365-704-0	No. 2 Bearing	None
CFMI	CFM56-3	305-366-202-0	No. 2 Bearing	None
CFMI	CFM56-3	305-366-203-0	No. 2 Bearing	None
CFMI	CFM56-3	305-366-204-0	No. 2 Bearing	None
CFMI	CFM56-3	337-108-301-0	No. 2 Bearing	None
CFMI	CFM56-3	337-108-302-0	No. 2 Bearing	None
CFMI	CFM56-3	1362M76P02	No. 3 Bearing	None
CFMI	CFM56-3	1461M14P04	No. 3 Bearing	None
CFMI	CFM56-3	1461M15P04	No. 3 Bearing	None
CFMI	CFM56-3	1461M15P06	No. 3 Bearing	None
CFMI	CFM56-3	1461M16P02	No. 3 Bearing	None
CFMI	CFM56-3	1461M16P04	No. 3 Bearing	None
CFMI	CFM56-3	1461M16P06	No. 3 Bearing	None
CFMI	CFM56-3	9340M90P02	No. 3 Bearing	None
CFMI	CFM56-3	9340M90P06	No. 3 Bearing	None
CFMI	CFM56-3	9732M10P10	No. 3 Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-3	9732M10P12	No. 3 Bearing	None
CFMI	CFM56-3	9732M10P17	No. 3 Bearing	None
CFMI	CFM56-3	9732M10P18	No. 3 Bearing	None
CFMI	CFM56-3	305-355-622-0	No. 4 Bearing	None
CFMI	CFM56-3	305-355-625-0	No. 4 Bearing	None
CFMI	CFM56-3	305-355-715-0	No. 4 Bearing	None
CFMI	CFM56-3	305-355-717-0	No. 4 Bearing	None
CFMI	CFM56-3	305-355-718-0	No. 4 Bearing	None
CFMI	CFM56-3	305-355-720-0	No. 4 Bearing	None
CFMI	CFM56-3	335-352-301-0	No. 4 Bearing	None
CFMI	CFM56-3	335-352-302-0	No. 4 Bearing	None
CFMI	CFM56-3	335-352-303-0	No. 4 Bearing	None
CFMI	CFM56-3	335-352-304-0	No. 4 Bearing	None
CFMI	CFM56-3	335-352-305-0	No. 4 Bearing	None
CFMI	CFM56-3	340-167-901-0	No. 4 Bearing	None
CFMI	CFM56-3	340-167-902-0	No. 4 Bearing	None
CFMI	CFM56-3	340-167-905-0	No. 4 Bearing	None
CFMI	CFM56-3	340-167-906-0	No. 4 Bearing	None
CFMI	CFM56-3	305-351-902-0	No. 5 Bearing	None
CFMI	CFM56-3	305-351-905-0	No. 5 Bearing	None
CFMI	CFM56-3	305-352-002-0	No. 5 Bearing	None
CFMI	CFM56-3	305-352-003-0	No. 5 Bearing	None
CFMI	CFM56-3	305-352-004-0	No. 5 Bearing	None
CFMI	CFM56-3	337-108-401-0	No. 5 Bearing	None
CFMI	CFM56-5A	9541M89P01	Bearing	None
CFMI	CFM56-5A	9725M84P08	Bearing	None
CFMI	CFM56-5A	9725M84P09	Bearing	None
CFMI	CFM56-5A	9972M33P06	Bearing	None
CFMI	CFM56-5A	9972M33P07	Bearing	None
CFMI	CFM56-5A	9972M33P08	Bearing	None
CFMI	CFM56-5A	9972M34P08	Bearing	None
CFMI	CFM56-5A	9972M34P09	Bearing	None
CFMI	CFM56-5A	9972M34P10	Bearing	None
CFMI	CFM56-5A	301-480-320-0	Bearing	None
CFMI	CFM56-5A	301-480-323-0	Bearing	None
CFMI	CFM56-5A	301-480-326-0	Bearing	None
CFMI	CFM56-5A	301-480-920-0	Bearing	None
CFMI	CFM56-5A	301-480-923-0	Bearing	None
CFMI	CFM56-5A	301-480-926-0	Bearing	None
CFMI	CFM56-5A	305-100-410-0	Bearing	None
CFMI	CFM56-5A	305-100-413-0	Bearing	None
CFMI	CFM56-5A	305-100-415-0	Bearing	None
CFMI	CFM56-5A	305-115-100-0	Bearing	None
CFMI	CFM56-5A	305-115-103-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5A	305-115-104-0	Bearing	None
CFMI	CFM56-5A	305-115-300-0	Bearing	None
CFMI	CFM56-5A	305-115-303-0	Bearing	None
CFMI	CFM56-5A	305-115-306-0	Bearing	None
CFMI	CFM56-5A	305-148-201-0	Bearing	None
CFMI	CFM56-5A	305-148-202-0	Bearing	None
CFMI	CFM56-5A	335-304-401-0	Bearing	None
CFMI	CFM56-5A	335-304-402-0	Bearing	None
CFMI	CFM56-5A	335-304-403-0	Bearing	None
CFMI	CFM56-5A	335-304-901-0	Bearing	None
CFMI	CFM56-5A	335-304-902-0	Bearing	None
CFMI	CFM56-5A	335-304-903-0	Bearing	None
CFMI	CFM56-5A	340-052-602-0	Bearing	None
CFMI	CFM56-5A	340-054-502-0	Bearing	None
CFMI	CFM56-5A	340-055-901-0	Bearing	None
CFMI	CFM56-5A	340-056-201-0	Bearing	None
CFMI	CFM56-5A	301-480-220-0	Bearing	None
CFMI	CFM56-5A	301-480-221-0	Bearing	None
CFMI	CFM56-5A	301-480-223-0	Bearing	None
CFMI	CFM56-5A	301-480-225-0	Bearing	None
CFMI	CFM56-5A	301-481-220-0	Bearing	None
CFMI	CFM56-5A	301-481-223-0	Bearing	None
CFMI	CFM56-5A	301-481-225-0	Bearing	None
CFMI	CFM56-5A	305-132-701-0	Bearing	None
CFMI	CFM56-5A	305-132-702-0	Bearing	None
CFMI	CFM56-5A	335-304-101-0	Bearing	None
CFMI	CFM56-5A	335-304-102-0	Bearing	None
CFMI	CFM56-5A	335-304-103-0	Bearing	None
CFMI	CFM56-5A	335-304-601-0	Bearing	None
CFMI	CFM56-5A	335-304-602-0	Bearing	None
CFMI	CFM56-5A	335-304-603-0	Bearing	None
CFMI	CFM56-5A	340-056-401-0	Bearing	None
CFMI	CFM56-5A	305-364-002-0	No. 1 Bearing	None
CFMI	CFM56-5A	305-364-103-0	No. 1 Bearing	None
CFMI	CFM56-5A	337-108-201-0	No. 1 Bearing	None
CFMI	CFM56-5A	305-365-702-0	No. 2 Bearing	None
CFMI	CFM56-5A	305-365-704-0	No. 2 Bearing	None
CFMI	CFM56-5A	305-366-202-0	No. 2 Bearing	None
CFMI	CFM56-5A	305-366-203-0	No. 2 Bearing	None
CFMI	CFM56-5A	305-366-204-0	No. 2 Bearing	None
CFMI	CFM56-5A	337-108-301-0	No. 2 Bearing	None
CFMI	CFM56-5A	337-108-302-0	No. 2 Bearing	None
CFMI	CFM56-5A	1460M51P01	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	1460M51P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	1460M52P01	No. 3 Bearing, Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5A	1460M52P03	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	1460M52P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	1665M98P02	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	9542M60P01	No. 3 Bearing, Ball	None
CFMI	CFM56-5A	1361M71P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	1361M71P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	1364M91P01	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	1364M91P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	1364M91P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	9542M61P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	9542M61P03	No. 3 Bearing, Roller	None
CFMI	CFM56-5A	305-355-622-0	No. 4 Bearing	None
CFMI	CFM56-5A	305-355-625-0	No. 4 Bearing	None
CFMI	CFM56-5A	305-355-717-0	No. 4 Bearing	None
CFMI	CFM56-5A	305-355-718-0	No. 4 Bearing	None
CFMI	CFM56-5A	305-355-720-0	No. 4 Bearing	None
CFMI	CFM56-5A	335-352-301-0	No. 4 Bearing	None
CFMI	CFM56-5A	335-352-302-0	No. 4 Bearing	None
CFMI	CFM56-5A	335-352-303-0	No. 4 Bearing	None
CFMI	CFM56-5A	335-352-304-0	No. 4 Bearing	None
CFMI	CFM56-5A	335-352-305-0	No. 4 Bearing	None
CFMI	CFM56-5A	340-167-901-0	No. 4 Bearing	None
CFMI	CFM56-5A	340-167-902-0	No. 4 Bearing	None
CFMI	CFM56-5A	340-167-904-0	No. 4 Bearing	None
CFMI	CFM56-5A	340-167-905-0	No. 4 Bearing	None
CFMI	CFM56-5A	340-167-906-0	No. 4 Bearing	None
CFMI	CFM56-5A	305-351-902-0	No. 5 Bearing	None
CFMI	CFM56-5A	305-351-905-0	No. 5 Bearing	None
CFMI	CFM56-5A	305-352-002-0	No. 5 Bearing	None
CFMI	CFM56-5A	305-352-003-0	No. 5 Bearing	None
CFMI	CFM56-5A	305-352-004-0	No. 5 Bearing	None
CFMI	CFM56-5A	337-108-401-0	No. 5 Bearing	None
CFMI	CFM56-5B	1361M71P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5B	1361M71P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5B	1364M91P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5B	1364M91P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5B	1460M51P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5B	1460M52P03	No. 3 Bearing, Ball	None
CFMI	CFM56-5B	1460M52P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5B	1665M98P02	No. 3 Bearing, Ball	None
CFMI	CFM56-5B	301-480-220-0	Bearing	None
CFMI	CFM56-5B	301-480-221-0	Bearing	None
CFMI	CFM56-5B	301-480-223-0	Bearing	None
CFMI	CFM56-5B	301-480-225-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5B	301-480-320-0	Bearing	None
CFMI	CFM56-5B	301-480-323-0	Bearing	None
CFMI	CFM56-5B	301-480-326-0	Bearing	None
CFMI	CFM56-5B	301-480-920-0	Bearing	None
CFMI	CFM56-5B	301-480-923-0	Bearing	None
CFMI	CFM56-5B	301-480-926-0	Bearing	None
CFMI	CFM56-5B	301-481-220-0	Bearing	None
CFMI	CFM56-5B	301-481-223-0	Bearing	None
CFMI	CFM56-5B	301-481-225-0	Bearing	None
CFMI	CFM56-5B	305-100-410-0	Bearing	None
CFMI	CFM56-5B	305-100-413-0	Bearing	None
CFMI	CFM56-5B	305-100-415-0	Bearing	None
CFMI	CFM56-5B	305-115-100-0	Bearing	None
CFMI	CFM56-5B	305-115-103-0	Bearing	None
CFMI	CFM56-5B	305-115-104-0	Bearing	None
CFMI	CFM56-5B	305-115-300-0	Bearing	None
CFMI	CFM56-5B	305-115-303-0	Bearing	None
CFMI	CFM56-5B	305-115-306-0	Bearing	None
CFMI	CFM56-5B	305-132-701-0	Bearing	None
CFMI	CFM56-5B	305-132-702-0	Bearing	None
CFMI	CFM56-5B	305-351-905-0	No. 5 Bearing, Roller	None
CFMI	CFM56-5B	305-352-004-0	No. 5 Bearing, Roller	None
CFMI	CFM56-5B	305-355-622-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	305-355-625-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	305-355-717-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	305-355-718-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	305-355-720-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	305-364-002-0	No. 1 Bearing, Ball	None
CFMI	CFM56-5B	305-364-103-0	No. 1 Bearing, Ball	None
CFMI	CFM56-5B	305-365-702-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	305-365-704-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	305-366-203-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	305-366-204-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	335-304-101-0	Bearing	None
CFMI	CFM56-5B	335-304-102-0	Bearing	None
CFMI	CFM56-5B	335-304-103-0	Bearing	None
CFMI	CFM56-5B	335-304-401-0	Bearing	None
CFMI	CFM56-5B	335-304-402-0	Bearing	None
CFMI	CFM56-5B	335-304-403-0	Bearing	None
CFMI	CFM56-5B	335-304-601-0	Bearing	None
CFMI	CFM56-5B	335-304-602-0	Bearing	None
CFMI	CFM56-5B	335-304-603-0	Bearing	None
CFMI	CFM56-5B	335-304-901-0	Bearing	None
CFMI	CFM56-5B	335-304-902-0	Bearing	None
CFMI	CFM56-5B	335-304-903-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5B	335-352-301-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	335-352-302-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	335-352-303-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	335-352-304-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	335-352-305-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	337-108-201-0	No. 1 Bearing, Ball	None
CFMI	CFM56-5B	337-108-301-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	337-108-302-0	No. 2 Bearing, Roller	None
CFMI	CFM56-5B	337-108-401-0	No. 5 Bearing, Roller	None
CFMI	CFM56-5B	337-220-301-0	No. 5 Bearing, Roller	None
CFMI	CFM56-5B	340-052-602-0	Bearing	None
CFMI	CFM56-5B	340-054-502-0	Bearing	None
CFMI	CFM56-5B	340-055-901-0	Bearing	None
CFMI	CFM56-5B	340-056-201-0	Bearing	None
CFMI	CFM56-5B	340-056-401-0	Bearing	None
CFMI	CFM56-5B	340-167-901-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	340-167-902-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	340-167-904-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	340-167-905-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	340-167-906-0	No. 4 Bearing, Roller	None
CFMI	CFM56-5B	9541M89P01	Bearing	None
CFMI	CFM56-5B	9542M61P03	No. 3 Bearing, Roller	None
CFMI	CFM56-5B	9725M84P08	Bearing	None
CFMI	CFM56-5B	9725M84P09	Bearing	None
CFMI	CFM56-5B	9972M33P06	Bearing	None
CFMI	CFM56-5B	9972M33P07	Bearing	None
CFMI	CFM56-5B	9972M33P08	Bearing	None
CFMI	CFM56-5B	9972M34P08	Bearing	None
CFMI	CFM56-5B	9972M34P09	Bearing	None
CFMI	CFM56-5B	9972M34P10	Bearing	None
CFMI	CFM56-5C	1361M71P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	1361M71P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	1364M91P01	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	1364M91P02	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	1364M91P05	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	1460M51P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5C	1460M52P03	No. 3 Bearing, Ball	None
CFMI	CFM56-5C	1460M52P05	No. 3 Bearing, Ball	None
CFMI	CFM56-5C	1665M98P02	No. 3 Bearing, Ball	None
CFMI	CFM56-5C	301-480-220-0	Bearing	None
CFMI	CFM56-5C	301-480-221-0	Bearing	None
CFMI	CFM56-5C	301-480-223-0	Bearing	None
CFMI	CFM56-5C	301-480-225-0	Bearing	None
CFMI	CFM56-5C	301-480-320-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5C	301-480-323-0	Bearing	None
CFMI	CFM56-5C	301-480-326-0	Bearing	None
CFMI	CFM56-5C	301-480-920-0	Bearing	None
CFMI	CFM56-5C	301-480-923-0	Bearing	None
CFMI	CFM56-5C	301-480-926-0	Bearing	None
CFMI	CFM56-5C	301-481-220-0	Bearing	None
CFMI	CFM56-5C	301-481-223-0	Bearing	None
CFMI	CFM56-5C	301-481-225-0	Bearing	None
CFMI	CFM56-5C	305-100-410-0	Bearing	None
CFMI	CFM56-5C	305-100-413-0	Bearing	None
CFMI	CFM56-5C	305-100-415-0	Bearing	None
CFMI	CFM56-5C	305-115-100-0	Bearing	None
CFMI	CFM56-5C	305-115-103-0	Bearing	None
CFMI	CFM56-5C	305-115-104-0	Bearing	None
CFMI	CFM56-5C	305-115-300-0	Bearing	
CFMI	CFM56-5C	305-115-303-0	Bearing	None
CFMI	CFM56-5C	305-115-306-0	Bearing	None
CFMI	CFM56-5C	305-148-201-0	Bearing	None
CFMI	CFM56-5C	305-148-202-0	Bearing	None
CFMI	CFM56-5C	305-351-905-0	No. 5 Bearing	None
CFMI	CFM56-5C	305-352-004-0	No. 5 Bearing	None
CFMI	CFM56-5C	305-355-622-0	No. 4 Bearing	None
CFMI	CFM56-5C	305-355-625-0	No. 4 Bearing	None
CFMI	CFM56-5C	305-355-717-0	No. 4 Bearing	None
CFMI	CFM56-5C	305-355-718-0	No. 4 Bearing	None
CFMI	CFM56-5C	305-355-720-0	No. 4 Bearing	None
CFMI	CFM56-5C	305-364-002-0	No. 1 Bearing	None
CFMI	CFM56-5C	305-364-103-0	No. 1 Bearing	None
CFMI	CFM56-5C	335-304-101-0	Bearing	None
CFMI	CFM56-5C	335-304-102-0	Bearing	None
CFMI	CFM56-5C	335-304-103-0	Bearing	None
CFMI	CFM56-5C	335-304-401-0	Bearing	None
CFMI	CFM56-5C	335-304-402-0	Bearing	None
CFMI	CFM56-5C	335-304-403-0	Bearing	None
CFMI	CFM56-5C	335-304-601-0	Bearing	None
CFMI	CFM56-5C	335-304-602-0	Bearing	None
CFMI	CFM56-5C	335-304-603-0	Bearing	None
CFMI	CFM56-5C	335-304-901-0	Bearing	None
CFMI	CFM56-5C	335-304-902-0	Bearing	None
CFMI	CFM56-5C	335-304-903-0	Bearing	None
CFMI	CFM56-5C	335-352-301-0	No. 4 Bearing	None
CFMI	CFM56-5C	335-352-302-0	No. 4 Bearing	None
CFMI	CFM56-5C	335-352-303-0	No. 4 Bearing	None
CFMI	CFM56-5C	335-352-304-0	No. 4 Bearing	None
CFMI	CFM56-5C	335-352-305-0	No. 4 Bearing	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-5C	337-010-702-0	No. 2 Bearing	None
CFMI	CFM56-5C	337-010-703-0	No. 2 Bearing	None
CFMI	CFM56-5C	337-010-761-0	No. 2 Bearing	None
CFMI	CFM56-5C	337-108-201-0	No. 1 Bearing	None
CFMI	CFM56-5C	337-108-401-0	No. 5 Bearing	None
CFMI	CFM56-5C	337-205-401-0	No. 2 Bearing	None
CFMI	CFM56-5C	337-205-501-0	No. 2 Bearing	None
CFMI	CFM56-5C	337-205-601-0	No. 2 Bearing	None
CFMI	CFM56-5C	340-052-602-0	Bearing	None
CFMI	CFM56-5C	340-054-502-0	Bearing	None
CFMI	CFM56-5C	340-055-901-0	Bearing	None
CFMI	CFM56-5C	340-056-201-0	Bearing	None
CFMI	CFM56-5C	340-056-401-0	Bearing	None
CFMI	CFM56-5C	340-167-901-0	No. 4 Bearing	None
CFMI	CFM56-5C	340-167-902-0	No. 4 Bearing	None
CFMI	CFM56-5C	340-167-904-0	No. 4 Bearing	None
CFMI	CFM56-5C	340-167-905-0	No. 4 Bearing	None
CFMI	CFM56-5C	340-167-906-0	No. 4 Bearing	None
CFMI	CFM56-5C	9541M89P01	Bearing	None
CFMI	CFM56-5C	9542M61P03	No. 3 Bearing, Roller	None
CFMI	CFM56-5C	9725M84P08	Bearing	None
CFMI	CFM56-5C	9725M84P09	Bearing	None
CFMI	CFM56-5C	9972M33P06	Bearing	None
CFMI	CFM56-5C	9972M33P07	Bearing	None
CFMI	CFM56-5C	9972M33P08	Bearing	None
CFMI	CFM56-5C	9972M34P08	Bearing	None
CFMI	CFM56-5C	9972M34P09	Bearing	None
CFMI	CFM56-5C	9972M34P10	Bearing	None
CFMI	CFM56-7B	1361M71P02	No. 3 Bearing, Roller	None
CFMI	CFM56-7B	1361M71P05	No. 3 Bearing, Roller	None
CFMI	CFM56-7B	1364M91P02	No. 3 Bearing, Roller	None
CFMI	CFM56-7B	1364M91P05	No. 3 Bearing, Roller	None
CFMI	CFM56-7B	1460M51P05	No. 3 Bearing, Ball	None
CFMI	CFM56-7B	1460M52P03	No. 3 Bearing, Ball	None
CFMI	CFM56-7B	1460M52P05	No. 3 Bearing, Ball	None
CFMI	CFM56-7B	1665M98P02	No. 3 Bearing, Ball	None
CFMI	CFM56-7B	2124M95P02	No. 3 Bearing, Ball	None
CFMI	CFM56-7B	301-480-320-0	Bearing	None
CFMI	CFM56-7B	301-480-323-0	Bearing	None
CFMI	CFM56-7B	301-480-325-0	Bearing	None
CFMI	CFM56-7B	301-480-326-0	Bearing	None
CFMI	CFM56-7B	301-480-720-0	Bearing	None
CFMI	CFM56-7B	301-480-723-0	Bearing	None
CFMI	CFM56-7B	301-480-724-0	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-7B	301-480-726-0	Bearing	None
CFMI	CFM56-7B	301-480-920-0	Bearing	None
CFMI	CFM56-7B	301-480-923-0	Bearing	None
CFMI	CFM56-7B	301-480-924-0	Bearing	None
CFMI	CFM56-7B	301-480-926-0	Bearing	None
CFMI	CFM56-7B	305-115-100-0	Bearing	None
CFMI	CFM56-7B	305-115-101-0	Bearing	None
CFMI	CFM56-7B	305-115-103-0	Bearing	None
CFMI	CFM56-7B	305-115-104-0	Bearing	None
CFMI	CFM56-7B	305-115-200-0	Bearing	None
CFMI	CFM56-7B	305-115-201-0	Bearing	None
CFMI	CFM56-7B	305-115-205-0	Bearing	None
CFMI	CFM56-7B	305-115-300-0	Bearing	None
CFMI	CFM56-7B	305-115-303-0	Bearing	None
CFMI	CFM56-7B	305-115-305-0	Bearing	None
CFMI	CFM56-7B	305-115-306-0	Bearing	None
CFMI	CFM56-7B	305-351-905-0	No. 5 Bearing	None
CFMI	CFM56-7B	305-352-004-0	No. 5 Bearing	None
CFMI	CFM56-7B	305-355-717-0	No. 4 Bearing	None
CFMI	CFM56-7B	305-355-718-0	No. 4 Bearing	None
CFMI	CFM56-7B	305-355-720-0	No. 4 Bearing	None
CFMI	CFM56-7B	305-364-002-0	No. 1 Bearing	None
CFMI	CFM56-7B	305-364-103-0	No. 1 Bearing	None
CFMI	CFM56-7B	335-304-101-0	Bearing	None
CFMI	CFM56-7B	335-304-102-0	Bearing	None
CFMI	CFM56-7B	335-304-103-0	Bearing	None
CFMI	CFM56-7B	335-304-201-0	Bearing	None
CFMI	CFM56-7B	335-304-202-0	Bearing	None
CFMI	CFM56-7B	335-304-203-0	Bearing	None
CFMI	CFM56-7B	335-304-401-0	Bearing	None
CFMI	CFM56-7B	335-304-402-0	Bearing	None
CFMI	CFM56-7B	335-304-403-0	Bearing	None
CFMI	CFM56-7B	335-304-501-0	Bearing	None
CFMI	CFM56-7B	335-304-503-0	Bearing	None
CFMI	CFM56-7B	335-304-901-0	Bearing	None
CFMI	CFM56-7B	335-304-902-0	Bearing	None
CFMI	CFM56-7B	335-304-903-0	Bearing	None
CFMI	CFM56-7B	335-352-301-0	No. 4 Bearing	None
CFMI	CFM56-7B	335-352-302-0	No. 4 Bearing	None
CFMI	CFM56-7B	335-352-303-0	No. 4 Bearing	None
CFMI	CFM56-7B	335-352-304-0	No. 4 Bearing	None
CFMI	CFM56-7B	335-352-305-0	No. 4 Bearing	None
CFMI	CFM56-7B	337-108-201-0	No. 1 Bearing	None
CFMI	CFM56-7B	337-108-401-0	No. 5 Bearing	None
CFMI	CFM56-7B	337-205-401-0	No. 2 Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
CFMI	CFM56-7B	337-205-501-0	No. 2 Bearing	None
CFMI	CFM56-7B	337-205-601-0	No. 2 Bearing	None
CFMI	CFM56-7B	340-050-901-0	Bearing	None
CFMI	CFM56-7B	340-050-902-0	Bearing	None
CFMI	CFM56-7B	340-051-001-0	Bearing	None
CFMI	CFM56-7B	340-051-002-0	Bearing	None
CFMI	CFM56-7B	340-052-502-0	Bearing	None
CFMI	CFM56-7B	340-052-602-0	Bearing	None
CFMI	CFM56-7B	340-054-502-0	Bearing	None
CFMI	CFM56-7B	340-055-801-0	Bearing	None
CFMI	CFM56-7B	340-055-901-0	Bearing	None
CFMI	CFM56-7B	340-056-001-0	Bearing	None
CFMI	CFM56-7B	340-056-101-0	Bearing	None
CFMI	CFM56-7B	340-056-201-0	Bearing	None
CFMI	CFM56-7B	340-056-301-0	Bearing	None
CFMI	CFM56-7B	340-056-401-0	Bearing	None
CFMI	CFM56-7B	340-154-101-0	Bearing	None
CFMI	CFM56-7B	340-154-201-0	Bearing	None
CFMI	CFM56-7B	340-155-101-0	Bearing	None
CFMI	CFM56-7B	340-167-901-0	No. 4 Bearing	None
CFMI	CFM56-7B	340-167-902-0	No. 4 Bearing	None
CFMI	CFM56-7B	340-167-906-0	No. 4 Bearing	None
CFMI	CFM56-7B	340-252-801-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-252-802-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-252-901-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-252-902-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-253-001-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-253-002-0	No. 5 Bearing	None
CFMI	CFM56-7B	340-257-001-0	No. 1 Bearing	None
CFMI	CFM56-7B	340-257-101-0	No. 2 Bearing	None
CFMI	CFM56-7B	340-257-201-0	No. 5 Bearing	None
CFMI	CFM56-7B	9541M89P01	Bearing	None
CFMI	CFM56-7B	9542M61P03	No. 3 Bearing, Roller	None
CFMI	CFM56-7B	9725M84P08	Bearing	None
CFMI	CFM56-7B	9725M84P09	Bearing	None
CFMI	CFM56-7B	9972M33P06	Bearing	None
CFMI	CFM56-7B	9972M33P07	Bearing	None
CFMI	CFM56-7B	9972M33P08	Bearing	None
CFMI	CFM56-7B	9972M34P08	Bearing	None
CFMI	CFM56-7B	9972M34P09	Bearing	None
CFMI	CFM56-7B	9972M34P10	Bearing	None
P&W	JT8D-200	318195	Bearing- Ball	None
P&W	JT8D-200	318198	Bearing- Ball	None
P&W	JT8D-200	318486	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	JT8D-200	380006	Bearing- Ball	None
P&W	JT8D-200	383305	Bearing- Ball	None
P&W	JT8D-200	383306	Bearing- Ball	None
P&W	JT8D-200	383307	Bearing	None
P&W	JT8D-200	441736	Bearing- Ball	None
P&W	JT8D-200	446738	Bearing	None
P&W	JT8D-200	446739	Bearing- Ball	None
P&W	JT8D-200	446740	Bearing- Ball	None
P&W	JT8D-200	446742	Bearing- Roller	None
P&W	JT8D-200	446744	Bearing	None
P&W	JT8D-200	446745	Bearing- Ball	None
P&W	JT8D-200	446746	Bearing- Ball	None
P&W	JT8D-200	446747	Bearing	None
P&W	JT8D-200	446748	Bearing- Roller	None
P&W	JT8D-200	446749	Bearing- Roller	None
P&W	JT8D-200	447228	Bearing	None
P&W	JT8D-200	447229	Bearing- Roller	None
P&W	JT8D-200	447230	Bearing- Roller	None
P&W	JT8D-200	447231	Bearing	None
P&W	JT8D-200	447232	Bearing- Ball	None
P&W	JT8D-200	447233	Bearing- Ball	None
P&W	JT8D-200	447234	Bearing	None
P&W	JT8D-200	447235	Bearing- Roller	None
P&W	JT8D-200	447237	Bearing	None
P&W	JT8D-200	447238	Bearing-Ball	None
P&W	JT8D-200	447239	Bearing- Ball	None
P&W	JT8D-200	447240	Bearing	None
P&W	JT8D-200	447241	Bearing- Roller	None
P&W	JT8D-200	447243	Bearing	None
P&W	JT8D-200	447244	Bearing- Roller	None
P&W	JT8D-200	447245	Bearing- Roller	None
P&W	JT8D-200	457525	Bearing	None
P&W	JT8D-200	457526	Bearing- Ball	None
P&W	JT8D-200	467573	Bearing	None
P&W	JT8D-200	467574	Bearing- Ball	None
P&W	JT8D-200	467575	Bearing- Ball	None
P&W	JT8D-200	487049	Bearing- Roller	None
P&W	JT8D-200	488014	Bearing	None
P&W	JT8D-200	505420	Bearing- Ball	None
P&W	JT8D-200	505422	Bearing- Roller	None
P&W	JT8D-200	505423	Bearing- Ball	None
P&W	JT8D-200	505428	Bearing- Ball	None
P&W	JT8D-200	505429	Bearing- Ball	None
P&W	JT8D-200	505430	Bearing- Ball	None
P&W	JT8D-200	533071	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	JT8D-200	540399	Bearing- Ball	None
P&W	JT8D-200	568043	Bearing	None
P&W	JT8D-200	568045	Bearing- Roller	None
P&W	JT8D-200	623734	Bearing- Ball	None
P&W	JT8D-200	623735	Bearing	None
P&W	JT8D-200	636449	Bearing- Roller	None
P&W	JT8D-200	648538	Bearing	None
P&W	JT8D-200	648539	Bearing- Ball	None
P&W	JT8D-200	650520	Bearing- Ball	None
P&W	JT8D-200	693010	Bearing- Roller	None
P&W	JT8D-200	693649	Bearing	None
P&W	JT8D-200	694005	Bearing- Roller	None
P&W	JT8D-200	694006	Bearing- Roller	None
P&W	JT8D-200	701566	Bearing- Ball	None
P&W	JT8D-200	701567	Bearing- Ball	None
P&W	JT8D-200	701569	Bearing- Ball	None
P&W	JT8D-200	701570	Bearing	None
P&W	JT8D-200	701576	Bearing- Ball	None
P&W	JT8D-200	704523	No. 3 Bearing, Ball	None
P&W	JT8D-200	706105	Bearing	None
P&W	JT8D-200	706106	Bearing	None
P&W	JT8D-200	707677	Bearing	None
P&W	JT8D-200	709676	Bearing	None
P&W	JT8D-200	709677	Bearing	None
P&W	JT8D-200	714142	Bearing	None
P&W	JT8D-200	714143	Bearing	None
P&W	JT8D-200	717109	Bearing	None
P&W	JT8D-200	730967	Bearing	None
P&W	JT8D-200	730977	Bearing	None
P&W	JT8D-200	733022	Bearing	None
P&W	JT8D-200	735014	Bearing- Roller	None
P&W	JT8D-200	738181	Bearing- Roller	None
P&W	JT8D-200	738184	Bearing- Roller	None
P&W	JT8D-200	738185	Bearing- Roller	None
P&W	JT8D-200	738187	Bearing- Roller	None
P&W	JT8D-200	738188	Bearing- Roller	None
P&W	JT8D-200	738191	Bearing- Roller	None
P&W	JT8D-200	738194	Bearing- Roller	None
P&W	JT8D-200	739317	Bearing- Roller	None
P&W	JT8D-200	739319	Bearing- Roller	None
P&W	JT8D-200	739483	Bearing- Ball	None
P&W	JT8D-200	749179	Bearing- Ball	None
P&W	JT8D-200	751166	Bearing- Roller	None
P&W	JT8D-200	753043	Bearing	None
P&W	JT8D-200	759020	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	JT8D-200	759022	Bearing- Ball	None
P&W	JT8D-200	770604	Bearing- Roller	None
P&W	JT8D-200	770625	Bearing	None
P&W	JT8D-200	770626	Bearing-Ball	None
P&W	JT8D-200	770627	Bearing- Ball	None
P&W	JT8D-200	770628	Bearing- Ball	None
P&W	JT8D-200	770646	Bearing- Roller	None
P&W	JT8D-200	771317	Bearing	None
P&W	JT8D-200	777887	Bearing	None
P&W	JT8D-200	777889	Bearing- Ball	None
P&W	JT8D-200	783368	Bearing	None
P&W	JT8D-200	795746	Bearing	None
P&W	JT8D-200	799764	Bearing- Ball	None
P&W	JT8D-200	799838	Bearing- Ball	None
P&W	JT8D-200	799839	Bearing- Ball	None
P&W	JT8D-200	799840	Bearing- Ball	None
P&W	JT8D-200	799841	Bearing- Ball	None
P&W	JT8D-200	799843	Bearing- Ball	None
P&W	JT8D-200	799844	Bearing- Ball	None
P&W	JT8D-200	799890	Bearing- Ball	None
P&W	JT8D-200	802053	Bearing- Ball	None
P&W	JT8D-200	804059	Bearing	None
P&W	JT8D-200	804061	Bearing- Ball	None
P&W	JT8D-200	805489	Bearing- Roller	None
P&W	JT8D-200	807675	Bearing- Ball	None
P&W	JT8D-200	807676	Bearing	None
P&W	JT8D-200	807678	Bearing	None
P&W	JT8D-200	810665	Bearing- Ball	None
P&W	JT8D-200	811990	Bearing- Roller	None
P&W	JT8D-200	815718	Bearing- Roller	None
P&W	JT8D-200	815733	Bearing- Roller	None
P&W	JT8D-200	815759	Bearing- Ball	None
P&W	JT8D-200	815760	Bearing	None
P&W	JT8D-200	815762	Bearing- Ball	None
P&W	JT8D-200	815763	Bearing- Roller	None
P&W	JT8D-200	815764	Bearing- Ball	None
P&W	JT8D-200	815765	Bearing	None
P&W	JT8D-200	815766	Bearing- Ball	None
P&W	JT8D-200	815767	Bearing- Roller	None
P&W	JT8D-200	815768	Bearing- Ball	None
P&W	JT8D-200	815769	Bearing- Roller	None
P&W	JT8D-200	815770	Bearing- Ball	None
P&W	JT8D-200	815780	Bearing- Ball	None
P&W	JT8D-200	815788	Bearing	None
P&W	JT8D-200	819091	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	JT8D-200	819499	Bearing	None
P&W	JT8D-200	819500	Bearing	None
P&W	JT8D-200	819771	Bearing	None
P&W	JT8D-200	820092	Bearing	None
P&W	JT8D-200	820093	Bearing	None
P&W	JT8D-200	820094	Bearing	None
P&W	JT8D-200	820095	Bearing	None
P&W	JT8D-200	820096	Bearing	None
P&W	JT8D-200	820097	Bearing	None
P&W	JT8D-200	820098	Bearing	None
P&W	JT8D-200	820099	Bearing	None
P&W	JT8D-200	820100	Bearing	None
P&W	JT8D-200	820154	Bearing- Roller	None
P&W	JT8D-200	820394	Bearing	None
P&W	JT8D-200	821255	Bearing- Ball	None
P&W	JT8D-200	821256	Bearing- Roller	None
P&W	JT8D-200	821930	Bearing- Ball	None
P&W	JT8D-200	821932	Bearing- Roller	None
P&W	JT8D-200	821934	Bearing- Roller	None
P&W	JT8D-200	821935	Bearing- Ball	None
P&W	JT8D-200	821936	Bearing- Roller	None
P&W	JT8D-200	822046	Bearing- Ball	None
P&W	JT8D-200	822047	Bearing- Ball	None
P&W	JT8D-200	822131	Bearing- Roller	None
P&W	JT8D-200	5004378-01	Bearing- Ball	None
IAE	V-2500 A1-A5	2A0000	No. 4 Bearing, Roller	None
IAE	V-2500 A1-A5	2A0001	No. 4 Bearing, Roller	None
IAE	V-2500 A1-A5	2A0003	No. 4 Bearing, Roller	None
IAE	V-2500 A1-A5	2A0006	No. 4 Bearing, Roller	None
IAE	V-2500 A1-A5	2A1165	No. 3 Bearing,Ball	None
IAE	V-2500 A1-A5	2A1170	No. 3 Bearing,Ball	None
IAE	V-2500 A1-A5	2A1250	No. 3 Bearing,Ball	None
IAE	V-2500 A1-A5	2A2134	No. 5 Bearing, Roller	None
IAE	V-2500 A1-A5	2A2136	No. 5 Bearing, Roller	None
IAE	V-2500 A1-A5	2A2255	Bearing-Roller	None
IAE	V-2500 A1-A5	2A3851	No. 3 Bearing,Ball	None
IAE	V-2500 A1-A5	2A4022	No. 3 Bearing,Ball	None
IAE	V-2500 A1-A5	2A4170	#3 BEARING BALL	None
IAE	V-2500 A1-A5	2A4235	#3 BEARING BALL	None
IAE	V-2500 A1-A5	4T0010	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0011	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0013	Bearing	None
IAE	V-2500 A1-A5	4T0014	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0015	Bearing-Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
IAE	V-2500 A1-A5	4T0020	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0021	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0023	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0024	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0025	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0040	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0041	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0043	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0044	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0050	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0051	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0053	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0053	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0054	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0055	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0060	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0061	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0063	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0064	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0065	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0070	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0071	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0073	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0074	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0075	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0080	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0081	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0083	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0085	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0087	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0088	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0089	Bearing- Ball	None
IAE	V-2500 A1-A5	4T0090	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0091	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0093	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0094	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0095	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0100	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0101	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0103	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0105	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0106	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0108	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0109	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0120	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0121	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0122	Bearing-Roller	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
IAE	V-2500 A1-A5	4T0123	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0124	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0165	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0168	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0170	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0171	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0173	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0174	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0174	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0175	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0180	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0181	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0183	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0184	Bearing-Roller	None
IAE	V-2500 A1-A5	4T0185	Bearing-Roller	None
IAE	V-2500 A1-A5	4T8001	#5 ROLLER BRG	None
IAE	V-2500 A1-A5	4T8005	#5 ROLLER BRG	None
IAE	V-2500 A1-A5	4T8009	#5 ROLLER BRG	None
IAE	V-2500 A1-A5	5A0497	Bearing	None
IAE	V-2500 A1-A5	5A0913	Bearing-Roller	None
IAE	V-2500 A1-A5	5A1428	Bearing	None
IAE	V-2500 A1-A5	5A1605	Bearing-Roller	None
IAE	V-2500 A1-A5	5A6221	Bearing-Ball	None
IAE	V-2500 A1-A5	5A6228	Bearing-Roller	None
IAE	V-2500 A1-A5	5A6229	Bearing-Roller	None
IAE	V-2500 A1-A5	5A6230	Bearing-Roller	None
IAE	V-2500 A1-A5	5A6231	ROLLER BRG OUTER	None
IAE	V-2500 A1-A5	5A7968	No. 1 Bearing, Ball	None
IAE	V-2500 A1-A5	5A7969	Bearing	None
IAE	V-2500 A1-A5	5A913	Bearing-Roller	None
IAE	V-2500 A1-A5	5R6002	No. 2 Bearing, Roller	None
IAE	V-2500 A1-A5	5R6003	No. 2 Bearing, Roller	None
IAE	V-2500 A1-A5	5R6004	#2 ROLL BRG OUTER	None
IAE	V-2500 A1-A5	5R6005	#2 ROLL BRG INNER	None
IAE	V-2500 A1-A5	7T7100	Bearing-Roller	None
IAE	V-2500 A1-A5	7T7102	Bearing-Roller	None
IAE	V-2500 A1-A5	7T0110	Bearing-Roller	None
GE	CF6-80C2	1327M76P01	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M76P03	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M77P03	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M77P04	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M77P05	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M78P03	No. 5R Bearing, Roller	None
GE	CF6-80C2	1327M96P01	No. 2 Bearing, Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-80C2	1333M85P01	No. 4R Bearing, Roller	None
GE	CF6-80C2	1333M85P02	No. 4R Bearing, Roller	None
GE	CF6-80C2	1333M86P01	No. 4R Bearing, Roller	None
GE	CF6-80C2	1333M86P02	No. 4R Bearing, Roller	None
GE	CF6-80C2	1333M87P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	1333M88P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	1333M89P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	1340M75P01	Bearing- Ball	None
GE	CF6-80C2	1340M75P02	Bearing-Ball	None
GE	CF6-80C2	1340M76P01	Bearing- Ball	None
GE	CF6-80C2	1340M77P01	Bearing- Roller	None
GE	CF6-80C2	1340M77P02	Bearing- Roller	None
GE	CF6-80C2	1340M78P01	Bearing- Ball	None
GE	CF6-80C2	1340M79P01	Bearing- Ball	None
GE	CF6-80C2	1340M80P01	Bearing- Roller	None
GE	CF6-80C2	1340M80P01	Bearing- Roller	None
GE	CF6-80C2	1340M84P01	Bearing- Ball	None
GE	CF6-80C2	1380M52P01	No. 1 Bearing, Ball	None
GE	CF6-80C2	1380M52P02	No. 1 Bearing, Ball	None
GE	CF6-80C2	1459M40P02	No. 1 Bearing, Ball	None
GE	CF6-80C2	1459M41P01	No. 3 Bearing, Roller	None
GE	CF6-80C2	1459M42P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	1459M43P01	No. 5R Bearing, Roller	None
GE	CF6-80C2	1459M43P02	No. 5R Bearing, Roller	None
GE	CF6-80C2	1471M99P01	No. 2 Bearing, Roller	None
GE	CF6-80C2	1471M99P01	Bearing, Roller	None
GE	CF6-80C2	1585M12P01	No. 3 Bearing, Roller	None
GE	CF6-80C2	1665M59P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	1665M59P02	No. 4B Bearing, Ball	None
GE	CF6-80C2	1851M19P01	Bearing- Ball	None
GE	CF6-80C2	1851M45P01	No. 2 Bearing, Roller	None
GE	CF6-80C2	1853M96P01	No. 4 Bearing, Roller	None
GE	CF6-80C2	1959M21P01	No. 4 Bearing, Roller	None
GE	CF6-80C2	2440M01P01	Bearing- Roller	None
GE	CF6-80C2	2443M00P01	Bearing- Ball	None
GE	CF6-80C2	2443M01P01	Bearing- Ball	None
GE	CF6-80C2	2443M02P01	Bearing- Ball	None
GE	CF6-80C2	2443M04P01	Bearing- Roller	None
GE	CF6-80C2	2443M05P01	Bearing- Roller	None
GE	CF6-80C2	2443M06P01	Bearing- Roller	None
GE	CF6-80C2	2443M07P01	Bearing- Roller	None
GE	CF6-80C2	2445M01P01	Bearing- Ball	None
GE	CF6-80C2	2445M02P01	Bearing- Ball	None
GE	CF6-80C2	9009M45P04	Bearing	None
GE	CF6-80C2	9009M45P05	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-80C2	9032M68P02	Bearing	None
GE	CF6-80C2	9032M68P03	Bearing	None
GE	CF6-80C2	9032M68P04	Bearing	None
GE	CF6-80C2	9046M13P03	No. 3 Bearing, Roller	None
GE	CF6-80C2	9143M89P01	No. 3 Bearing, Roller	None
	CF6-80C2	9195M71P01	No. 3 Bearing, Roller	None
GE	CF6-80C2	9218M65P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	9244M15P03	No. 1 Bearing, Ball	None
GE	CF6-80C2	9244M15P04	No. 1 Bearing, Ball	None
GE	CF6-80C2	9244M15P05	No. 1 Bearing, Ball	None
GE	CF6-80C2	9244M51P01	No. 4B Bearing, Ball	None
GE	CF6-80C2	9312M83P03	No. 1 Bearing, Ball	None
GE	CF6-80C2	9312M83P04	No. 1 Bearing, Ball	None
GE	CF6-80C2	9329M85P02	No. 3 Bearing- Roller	None
GE	CF6-80C2	9329M85P05	No. 3 Bearing- Roller	None
GE	CF6-80C2	9329M86P02	No. 3 Bearing- Roller	None
GE	CF6-80C2	9372M13P01	Bearing- Roller	None
GE	CF6-80C2	9372M14P01	Bearing- Roller	None
GE	CF6-80C2	9372M15P01	Bearing- Roller	None
GE	CF6-80C2	9372M16P01	Bearing- Roller	None
GE	CF6-80C2	9372M17P01	Bearing- Roller	None
GE	CF6-80C2	9372M18P01	Bearing- Ball	None
GE	CF6-80C2	9372M19P01	Bearing- Ball	None
GE	CF6-80C2	9372M20P01	Bearing	None
GE	CF6-80C2	9372M21P01	Bearing- Ball	None
GE	CF6-80C2	9372M23P01	Bearing- Ball	None
GE	CF6-80C2	9372M24P01	Bearing- Ball	None
GE	CF6-80C2	9372M29P01	Bearing	None
GE	CF6-80C2	9372M29P02	Bearing	None
GE	CF6-80C2	9372M30P02	Bearing- Ball	None
GE	CF6-80C2	9372M31P01	Bearing- Roller	None
GE	CF6-80C2	9372M31P02	Bearing- Roller	None
GE	CF6-80C2	9372M34P01	Bearing- Ball	None
GE	CF6-80C2	9372M71P01	Bearing- Ball	None
GE	CF6-80C2	9372M72P01	Bearing- Ball	None
GE	CF6-80C2	9379M25P06	No. 4R Bearing, Roller	None
GE	CF6-80C2	9379M26P06	No. 4R Bearing, Roller	None
GE	CF6-80C2	9382M78P01	Bearing- Ball	None
GE	CF6-80C2	9382M78P01	Bearing- Ball	None
GE	CF6-80C2	9392M31P01	Bearing- Ball	None
GE	CF6-80C2	9392M31P01	Bearing- Ball	None
GE	CF6-80C2	9395M37P01	Bearing- Roller	None
GE	CF6-80C2	9395M37P01	Bearing- Roller	None
GE	CF6-80C2	9395M90P01	Bearing- Ball	None
GE	CF6-80C2	9397M25P01	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-80C2	9397M26P01	Bearing- Roller	None
GE	CF6-80C2	9397M27P01	Bearing- Roller	None
GE	CF6-80C2	9397M28P02	Bearing- Roller	None
GE	CF6-80C2	9397M29P01	Bearing- Roller	None
GE	CF6-80C2	9397M30P01	Bearing- Ball	None
GE	CF6-80C2	9397M31P01	Bearing- Ball	None
GE	CF6-80C2	9397M33P01	Bearing	None
GE	CF6-80C2	9397M34P01	Bearing- Ball	None
GE	CF6-80C2	9397M35P01	Bearing- Ball	None
GE	CF6-80C2	9397M36P01	Bearing- Ball	None
GE	CF6-80C2	9600M76P04	Bearing	None
GE	CF6-80C2	9600M76P04	Bearing- Ball	None
GE	CF6-80C2	9600M76P06	Bearing	None
GE	CF6-80C2	9600M76P06	Bearing- Ball	None
GE	CF6-80C2	9600M76P09	Bearing	None
GE	CF6-80C2	9600M76P09	Bearing- Ball	None
GE	CF6-80C2	9600M78P01	Bearing- Roller	None
GE	CF6-80C2	9600M78P02	Bearing- Roller	None
GE	CF6-80C2	9600M78P03	Bearing- Roller	None
GE	CF6-80C2	9600M91P05	Bearing- Roller	None
GE	CF6-80C2	9600M91P05	Bearing- Roller	None
GE	CF6-80C2	9648M01P08	No. 4 Bearing, Ball	None
GE	CF6-80C2	9658M51P03	No. 2 Bearing, Roller	None
GE	CF6-80C2	9658M51P04	No. 2 Bearing, Roller	None
GE	CF6-80C2	9600M76P07	Bearing- Ball	None
GE	CF6-80C2	9600M76P07	Bearing- Ball	None
GE	CF6-80C2	9699M16P03	Bearing- Ball	None
GE	CF6-80C2	1333M86P02	Bearing-Roller	None
GE	CF6-80C2	1518M37P17	Bearing	None
GE	CF6-80C2	1518M37P20	Bearing	None
GE	CF6-80C2	R1835E111	#3R Bearing	None
GE	CF6-80C2	R1842E116	#6R Bearing	None
GE	CF6-80C2	91968U109	#1B Bearing	None
GE	CF6-80C2	91934U105	#4R Bearing	None
GE	CF6-80C2	R1834EJ111	#2 Inner Ring only	None
GE	CF6-80C2	9146M72P15	#2 Inner Ring only	None
GE	CF6-50	1327M96P01	Bearing- Roller	None
GE	CF6-50	1471M99P01	Bearing- Roller	None
GE	CF6-50	1585M12P01	No. 3 Bearing, Roller	None
GE	CF6-50	1851M45P01	Bearing- Roller	None
GE	CF6-50	1853M96P01	No. 4 Bearing, Roller	None
GE	CF6-50	1959M21P01	No. 4 Bearing, Roller	None
GE	CF6-50	1959M22P01	No. 4B Bearing, Ball	None
GE	CF6-50	1959M24P01	No. 6 Bearing, Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-50	1959M28P01	No. 5 Bearing, Roller	None
GE	CF6-50	1962M25P01	Bearing- Ball	None
GE	CF6-50	1962M44P01	No. 5 Bearing, Roller	None
GE	CF6-50	1962M51P01	Bearing- Roller	None
GE	CF6-50	1962M52P01	Bearing- Roller	None
GE	CF6-50	1962M54P01	Bearing	None
GE	CF6-50	1962M58P01	Bearing- Ball	None
GE	CF6-50	2140M94P01	No. 4B Bearing, Ball	None
GE	CF6-50	9009M45P01	Bearing- Ball	None
GE	CF6-50	9009M45P03	Bearing	None
GE	CF6-50	9009M45P04	Bearing- Ball	None
GE	CF6-50	9009M45P05	Bearing- Ball	None
GE	CF6-50	9032M68P02	Bearing	None
GE	CF6-50	9032M68P03	Bearing- Ball	None
GE	CF6-50	9032M68P04	Bearing- Ball	None
GE	CF6-50	9046M13P03	No. 3 Bearing, Roller	None
GE	CF6-50	9081M69P01	No. 5 Bearing, Roller	None
GE	CF6-50	9081M69P02	No. 5 Bearing, Roller	None
GE	CF6-50	9143M27P01	Bearing- Ball	None
GE	CF6-50	9143M28P01	Bearing- Ball	None
GE	CF6-50	9143M29P01	Bearing- Roller	None
GE	CF6-50	9143M89P01	No. 3 Bearing, Roller	None
GE	CF6-50	9146M72P03	Bearing	None
GE	CF6-50	9146M72P04	Bearing	None
GE	CF6-50	9146M72P05	Bearing	None
GE	CF6-50	9146M72P06	Bearing	None
GE	CF6-50	9195M71P01	No. 3 Bearing, Roller	None
GE	CF6-50	9195M71P02	No. 3 Bearing, Roller	None
GE	CF6-50	9600M64P03	Bearing	None
GE	CF6-50	9600M64P11	Bearing	None
GE	CF6-50	9600M76P04	Bearing - Ball	None
GE	CF6-50	9600M76P04	Bearing - Ball	None
GE	CF6-50	9600M76P06	Bearing- Ball	None
GE	CF6-50	9600M76P07	Bearing- Ball	None
GE	CF6-50	9600M76P09	Bearing- Ball	None
GE	CF6-50	9600M78P01	Bearing- Roller	None
GE	CF6-50	9600M78P02	Bearing- Roller	None
GE	CF6-50	9600M78P03	Bearing- Roller	None
GE	CF6-50	9600M78P04	Bearing- Roller	None
GE	CF6-50	9600M91P04	Bearing- Roller	None
GE	CF6-50	9600M91P04	Bearing- Roller	None
GE	CF6-50	9600M91P05	Bearing- Roller	None
GE	CF6-50	9600M91P05	Bearing- Roller	None
GE	CF6-50	9600M91P06	Bearing- Roller	None
GE	CF6-50	9600M91P07	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-50	9600M94P05	Bearing- Roller	None
GE	CF6-50	9600M94P06	Bearing- Roller	None
GE	CF6-50	9600M94P08	Bearing- Roller	None
GE	CF6-50	9601M01P04	Bearing- Ball	None
GE	CF6-50	9601M03P01	Bearing- Ball	None
GE	CF6-50	9601M03P03	Bearing- Ball	None
GE	CF6-50	9601M03P06	Bearing- Ball	None
GE	CF6-50	9648M01P08	No. 4 Bearing, Ball	None
GE	CF6-50	9648M01P12	No. 3 Bearing, Roller	None
GE	CF6-50	9648M01P13	No. 3 Bearing, Roller	None
GE	CF6-50	9648M01P14	No. 4B Bearing, Ball	None
GE	CF6-50	9648M01P15	No. 4B Bearing, Ball	None
GE	CF6-50	9658M51P03	Bearing- Roller	None
GE	CF6-50	9658M51P04	Bearing- Roller	None
GE	CF6-50	9658M53P02	No. 6 Bearing, Roller	None
GE	CF6-50	9658M53P03	No. 6 Bearing, Roller	None
GE	CF6-50	9658M54P03	No. 7 Bearing, Roller	None
GE	CF6-50	9658M54P04	No. 7 Bearing, Roller	None
GE	CF6-50	9671M26P06	No. 4 Bearing, Roller	None
GE	CF6-50	9671M26P08	No. 4 Bearing, Roller	None
GE	CF6-50	9671M26P09	No. 4 Bearing, Roller	None
GE	CF6-50	9685M49P04	No. 5 Bearing, Roller	None
GE	CF6-50	9685M49P08	No. 5 Bearing, Roller	None
GE	CF6-50	9690M72P04	No.1 Bearing, Ball	None
GE	CF6-50	9690M72P06	No.1 Bearing, Ball	None
GE	CF6-50	9690M72P07	No.1 Bearing, Ball	None
GE	CF6-50	9698M64P01	Bearing	None
GE	CF6-50	9699M01P02	Bearing	None
GE	CF6-50	9699M01P02	Bearing	None
GE	CF6-50	9699M01P03	Bearing	None
GE	CF6-50	9699M02P02	Bearing	None
GE	CF6-50	9699M02P03	Bearing	None
GE	CF6-50	9699M03P01	Bearing	None
GE	CF6-50	9699M03P02	Bearing	None
GE	CF6-50	9699M04P01	Bearing- Roller	None
GE	CF6-50	9699M04P02	Bearing- Roller	None
GE	CF6-50	9699M06P01	Bearing	None
GE	CF6-50	9699M06P02	Bearing	None
GE	CF6-50	9699M07P01	Bearing- Ball	None
GE	CF6-50	9699M07P02	Bearing- Ball	None
GE	CF6-50	9699M07P08	Bearing- Ball	None
GE	CF6-50	9699M07P09	Bearing- Ball	None
GE	CF6-50	9699M08P01	Bearing- Ball	None
GE	CF6-50	9699M08P02	Bearing- Ball	None
GE	CF6-50	9699M08P03	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF6-50	9699M09P01	Bearing	None
GE	CF6-50	9699M09P03	Bearing	None
GE	CF6-50	9699M11P01	Bearing- Ball	None
GE	CF6-50	9699M11P02	Bearing- Ball	None
GE	CF6-50	9699M12P01	Bearing	None
GE	CF6-50	9699M12P02	Bearing	None
GE	CF6-50	9699M14P01	Bearing	None
GE	CF6-50	9699M14P02	Bearing	None
GE	CF6-50	9699M15P01	Bearing	None
GE	CF6-50	9699M15P02	Bearing	None
GE	CF6-50	9699M16P01	Bearing- Ball	None
GE	CF6-50	9699M16P03	Bearing- Ball	None
GE	CF6-50	1962M47P01	No. 6 Bearing, Roller	None
GE	CF6-50	1962M50P01	Bearing- Duplex	None
GE	CF6-50	9009M45P03	Bearing- Duplex	None
GE	CF6-50	9032M68P02	Bearing- Duplex	None
GE	CF6-50	9032M68P03	Bearing- Duplex	None
GE	CF6-50	9032M68P04	Bearing- Duplex	None
GE	CF6-50	9143M26P01	Bearing- Ball	None
GE	CF6-50	9312M49P01	Bearing- Ball	None
GE	CF6-50	9600M76P04	Bearing- Duplex	None
GE	CF6-50	9658M5104	Bearing- Roller	None
GE	CF6-80C2	9329M85P02	#3R Bearing	None
GE	CF6-80C2	R1835E111	#3R Bearing	None
GE	CF6-80C2	9356M16P05	#6R Bearing	None
GE	CF6-80C2	R1842E116	#6R Bearing	None
GE	CF6-80C2	91968U109	#1B Bearing	None
GE	CF6-80C2	9244M15P03	#1B Bearing	None
GE	CF6-80C2	9312M83P03	#1B Bearing	None
GE	CF6-80C2	1333M85P01	#4R Bearing	None
GE	CF6-80C2	1333M85P02	#4R Bearing	None
GE	CF6-80C2	1333M88P01	#4R Bearing	None
GE	CF6-80C2	91934U105	#4R Bearing	None
GE	CF6-80C2	1327M77P04	#5R Bearing	None
GE	CF6-80C2	R1834EJ111	#2 Inner Ring only	None
GE	CF6-80C2	9146M72P15	#2 Inner Ring only	None
P&WC	PT6A-65B, R, AR	3031683	Bearing- Ball	None
P&WC	PT6A-65B, R, AR	3026892	Bearing- Ball	None
P&WC	PT6A-65B, R, AR	3032657	Bearing	None
P&WC	PT6A-65B, R, AR	3030925	Bearing- Ball	None
P&WC	PT6A-65B, R, AR	3101649-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3032208	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3119807-01	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-65B, R, AR, AG	3072811-01	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3109210-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3072789-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3112696-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3112696-03	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3006146	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3028004	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3031717	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3073900-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3102455-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3032208	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3119806-01	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3072810-01	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3109209-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3112117-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3112117-02	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3112117-03	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3072788-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3073900-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3006146	No. 2 Bearing, Roller	None
P&WC	PT6A-65B, R, AR, AG	3028004	No. 2 Bearing, Roller	None
P&WC	PT6A-65B, R, AR, AG	3031717	No. 2 Bearing, Roller	None
P&WC	PT6A-65B, R, AR, AG	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6A-65B, R, AR, AG	3010674	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3023377	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3023378	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3023379	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3028005	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3031724	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3032209	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3032647	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3032648	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3032649	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3037278	Bearing	None
P&WC	PT6A-65B, R, AR, AG	3073908-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3100619-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3100624-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3100632-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3101634-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3101636-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3101647-01	Bearing- Ball	None
P&WC	PT6A-65B, R, AR, AG	3102465-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3107500-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3107504-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3112367-01	Bearing- Roller	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-65B, R, AR, AG	3112368-01	Bearing- Roller	None
P&WC	PT6A-65B, R, AR, AG	3112369-01	Bearing- Roller	None
P&WC	PT6A-65AR	3023377	Bearing- Roller	None
P&WC	PT6A-65AR	3023378	Bearing- Roller	None
P&WC	PT6A-65AR	3023379	Bearing- Ball	None
P&WC	PT6A-65AR	3032647	Bearing	None
P&WC	PT6A-65AR	3032648	Bearing	None
P&WC	PT6A-65AR	3032649	Bearing	None
P&WC	PT6A-65AR	3100619-01	Bearing- Roller	None
P&WC	PT6A-65AR	3100624-01	Bearing- Ball	None
P&WC	PT6A-65AR	3100632-01	Bearing- Roller	None
P&WC	PT6A-65AR	3101634-01	Bearing- Roller	None
P&WC	PT6A-65AR	3101647-01	Bearing- Ball	None
P&WC	PT6A-65AR	3102465-01	Bearing- Roller	None
P&WC	PT6A-65AR	3107500-01	Bearing- Roller	None
P&WC	PT6A-65AR	3107504-01	Bearing- Roller	None
P&WC	PT6A-65	3006146	No. 2 Bearing, Roller	None
P&WC	PT6A-65	3006146	Bearing- Roller	None
P&WC	PT6A-65	3010674	Bearing- Roller	None
P&WC	PT6A-65	3026892	Bearing- Ball	None
P&WC	PT6A-65	3028004	No. 2 Bearing, Roller	None
P&WC	PT6A-65	3028004	Bearing- Roller	None
P&WC	PT6A-65	3028005	Bearing- Roller	None
P&WC	PT6A-65	3030925	Bearing- Ball	None
P&WC	PT6A-65	3031683	Bearing- Ball	None
P&WC	PT6A-65	3031717	No. 2 Bearing, Roller	None
P&WC	PT6A-65	3031717	Bearing- Roller	None
P&WC	PT6A-65	3031724	Bearing- Roller	None
P&WC	PT6A-65	3032208	Bearing	None
P&WC	PT6A-65	3032209	Bearing	None
P&WC	PT6A-65	3032657	Bearing	None
P&WC	PT6A-65	3037278	Bearing	None
P&WC	PT6A-65	3119806	Bearing	None
P&WC	PT6A-65	3101636-01	Bearing- Roller	None
P&WC	PT6A-65	3101649-01	Bearing- Ball	None
P&WC	PT6A-65	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6A-65	3102455-01	Bearing- Roller	None
P&WC	PT6A-65	3109209-01	Bearing- Ball	None
P&WC	PT6A-65	3109210-01	Bearing- Ball	None
P&WC	PT6A-65	3112117-01	Bearing- Ball	None
P&WC	PT6A-65	3112117-02	Bearing- Ball	None
P&WC	PT6A-65	3112117-03	Bearing- Ball	None
P&WC	PT6A-65	3112367-01	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-65	3112368-01	Bearing- Roller	None
P&WC	PT6A-65	3112369-01	Bearing- Roller	None
P&WC	PT6A-65	3112696-01	Bearing- Ball	None
P&WC	PT6A-65	3112696-02	Bearing- Ball	None
P&WC	PT6A-65	3112696-03	Bearing- Ball	None
P&WC	PT6A-65	3119806-01	Bearing- Ball	None
P&WC	PT6A-65	3119807-01	Bearing- Ball	None
P&WC	PT6A67	3006146	No. 2 Bearing, Roller	None
P&WC	PT6A67	3006146	Bearing- Roller	None
P&WC	PT6A67	3010674	Bearing- Roller	None
P&WC	PT6A67	3028004	No. 2 Bearing, Roller	None
P&WC	PT6A67	3028004	Bearing- Roller	None
P&WC	PT6A67	3028005	Bearing- Roller	None
P&WC	PT6A67	3031717	No. 2 Bearing, Roller	None
P&WC	PT6A67	3031717	Bearing- Roller	None
P&WC	PT6A67	3031724	Bearing- Roller	None
P&WC	PT6A67	3032208	Bearing	None
P&WC	PT6A67	3032208	Bearing	None
P&WC	PT6A67	3032209	Bearing	None
P&WC	PT6A67	3037278	Bearing	None
P&WC	PT6A67	3101636-01	Bearing- Roller	None
P&WC	PT6A67	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6A67	3102455-01	Bearing- Roller	None
P&WC	PT6A67	3109210-01	Bearing- Ball	None
P&WC	PT6A67	3112367-01	Bearing- Roller	None
P&WC	PT6A67	3112368-01	Bearing- Roller	None
P&WC	PT6A67	3112369-01	Bearing- Roller	None
P&WC	PT6A67	3112696-01	Bearing- Ball	None
P&WC	PT6A67	3112696-02	Bearing- Ball	None
P&WC	PT6A67	3112696-03	Bearing- Ball	None
P&WC	PT6A67A	3113589-01	Bearing- Ball	None
P&WC	PT6A67	3119807-01	Bearing	None
P&WC	PT6A67A	3006146	No. 2 Bearing, Roller	None
P&WC	PT6A67A	3006146	Bearing- Roller	None
P&WC	PT6A67A	3010674	Bearing- Roller	None
P&WC	PT6A67A	3028004	No. 2 Bearing, Roller	None
P&WC	PT6A67A	3028004	Bearing- Roller	None
P&WC	PT6A67A	3028005	Bearing- Roller	None
P&WC	PT6A67A	3030925	Bearing- Ball	None
P&WC	PT6A67A	3031683	Bearing- Ball	None
P&WC	PT6A67A	3031717	No. 2 Bearing, Roller	None
P&WC	PT6A67A	3031717	Bearing- Roller	None
P&WC	PT6A67A	3031724	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A67A	3032208	Bearing	None
P&WC	PT6A67A	3032208	Bearing	None
P&WC	PT6A67A	3032209	Bearing	None
P&WC	PT6A67A	3037278	Bearing	None
P&WC	PT6A67A	3072788-01	Bearing- Ball	None
P&WC	PT6A67A	3072789-01	Bearing- Ball	None
P&WC	PT6A67A	3072810-01	Bearing	None
P&WC	PT6A67A	3072811-01	Bearing	None
P&WC	PT6A67A	3101636-01	Bearing- Roller	None
P&WC	PT6A67A	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6A67A	3102455-01	Bearing- Roller	None
P&WC	PT6A67A	3109209-01	Bearing- Ball	None
P&WC	PT6A67A	3109210-01	Bearing- Ball	None
P&WC	PT6A67A	3112117-01	Bearing- Ball	None
P&WC	PT6A67A	3112117-02	Bearing- Ball	None
P&WC	PT6A67A	3112117-03	Bearing- Ball	None
P&WC	PT6A67A	3112367-01	Bearing- Roller	None
P&WC	PT6A67A	3112368-01	Bearing- Roller	None
P&WC	PT6A67A	3112369-01	Bearing- Roller	None
P&WC	PT6A67A	3112696-01	Bearing- Ball	None
P&WC	PT6A67A	3112696-02	Bearing- Ball	None
P&WC	PT6A67A	3112696-03	Bearing- Ball	None
P&WC	PT6A67A	3113589-01	No. 1 Bearing, Ball	None
P&WC	PT6A67A	3119806-01	Bearing	None
P&WC	PT6A67A	3119807-01	Bearing	None
P&WC	PT6T3	3006146	No. 2 Bearing, Roller	None
P&WC	PT6T3	3006146	No. 3 Bearing, Roller	None
P&WC	PT6T3	3007194	No. 1 Bearing, Ball	None
P&WC	PT6T3	3009243	No. 4 Bearing, Ball	None
P&WC	PT6T3	3010674	Bearing- Roller	None
P&WC	PT6T3	3012927	Bearing- Ball	None
P&WC	PT6T3	3018940	Bearing- Ball	None
P&WC	PT6T3	3028003	No. 1 Bearing, Ball	None
P&WC	PT6T3	3028004	No. 2 Bearing, Roller	None
P&WC	PT6T3	3028004	No. 3 Bearing, Roller	None
P&WC	PT6T3	3028005	Bearing- Roller	None
P&WC	PT6T3	3028006	No. 4 Bearing, Ball	None
P&WC	PT6T3	3031717	No. 2 Bearing, Roller	None
P&WC	PT6T3	3031717	No. 3 Bearing, Roller	None
P&WC	PT6T3	3031724	Bearing- Roller	None
P&WC	PT6T3	3032208	Bearing	None
P&WC	PT6T3	3032208	Bearing	None
P&WC	PT6T3	3032209	Bearing	None
P&WC	PT6T3	3032621	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6T3	3032623	Bearing	None
P&WC	PT6T3	3032636	Bearing	None
P&WC	PT6T3	3033456	No. 1 Bearing, Ball	None
P&WC	PT6T3	3033459	No. 1 Bearing, Ball	None
P&WC	PT6T3	3033481	Bearing	None
P&WC	PT6T3	3037278	Bearing	None
P&WC	PT6T3	30288004	No. 3 Bearing, Roller	None
P&WC	PT6T3	3100626-01	Bearing- Ball	None
P&WC	PT6T3	3101635-01	No. 4 Bearing, Ball	None
P&WC	PT6T3	3101636-01	Bearing- Roller	None
P&WC	PT6T3	3101636-01	Bearing- Roller	None
P&WC	PT6T3	3101636-01	Bearing- Roller	None
P&WC	PT6T3	3101636-01	Bearing- Roller	None
P&WC	PT6T3	3101636-01	Bearing- Roller	None
P&WC	PT6T3	3101864-01	No. 1 Bearing, Ball	None
P&WC	PT6T3	3101866-01	Bearing- Ball	None
P&WC	PT6T3	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6T3	3102455-01	No. 3 Bearing, Roller	None
P&WC	PT6T3	3112367-01	Bearing- Roller	None
P&WC	PT6T3	3112368-01	Bearing- Roller	None
P&WC	PT6T3	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3006146	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3003474	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3005928	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3006146	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3006608	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3007194	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3008676	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3009243	Bearnig- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3010100	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3010674	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3028003	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3028004	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3028004	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3028005	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3028006	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3031717	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3031717	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3031724	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3032208	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3032208	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3032209	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3032621	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3032623	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3033459	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3033481	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3037278	Bearing	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073904	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073900-01	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073900-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073901-01	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073904-01	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3073908-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3101635-01	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3101636-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3101864-01	Bearing- Ball	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3102455-01	No. 2 Bearing, Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3102455-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3102455-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3102455-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112367-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112367-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112367-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112367-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112367-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112368-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6-6/-6A/-6B PT6-20/-20A/-20B	3112369-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -121	333481	Bearing	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -121	3006146	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -122	3007194	Bearing- Ball	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -122	3009243	Bearing- Ball	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -123	3010674	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -123	3028003	Bearing- Ball	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -124	3028004	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -124	3028004	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -125	3028005	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -125	3028006	Bearing- Ball	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -126	3031717	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -126	3031717	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -127	3031724	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -127	3032208	Bearing	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -128	3032208	Bearing	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -128	3032209	Bearing	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -129	3032621	Bearing	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -129	3032623	Bearing- Ball	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -130	3033459	Bearing- Ball	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -130	3033481	Bearing	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -131	3037278	Bearing-	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -131	3073900-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -132	3073900-01	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -132	3073901-01	Bearing- Ball	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -133	3073904-01	Bearing- Ball	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -133	3073908-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -134	3101635-01	Bearing- Ball	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -134	3101636-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -135	3101864-01	Bearing- Ball	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -135	3102455-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -136	3102455-01	Bearing- Roller	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -136	3112367-01	Bearing- Roller	None
P&WC	PT6A-11/ -11AG/ -15AG/ -110/ -112/ -137	3112368-01	Bearing-	None
P&WC	PT6-11/ -11AG/ -15AG/ -110/ -112/ -137	3112369-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3006146	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3032208	Bearing	None
P&WC	PT6A-21/ -27/ -28	3028004	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3102455-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3032208	Bearing	None
P&WC	PT6A-21/ -27/ -28	3073900-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3007194	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3032621	Bearing	None
P&WC	PT6A-21/ -27/ -28	3028003	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3101864-01	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3033481	Bearing	None
P&WC	PT6A-21/ -27/ -28	3033459	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3033481	Bearing	None
P&WC	PT6A-21/ -27/ -28	3073904	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	30317171	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3032623	Bearing	None
P&WC	PT6A-21/ -27/ -28	3009243	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3028006	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3101635-01	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3073901-01	Bearing- Ball	None
P&WC	PT6A-21/ -27/ -28	3006146	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3028004	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-21/ -27/ -28	3102455-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3032208	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3031717	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3073900-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3010674	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3032209	Bearing	None
P&WC	PT6A-21/ -27/ -28	3028005	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3031724	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3101636-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3037278	Bearing	None
P&WC	PT6A-21/ -27/ -28	3112367-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3112368-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3112369-01	Bearing- Roller	None
P&WC	PT6A-21/ -27/ -28	3073908-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3006146	No. 2, Bearing, Roller	None
P&WC	PT6A-25/ -25A	3032208	Bearing	None
P&WC	PT6A-25/ -25A	3102455-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3031717	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3073900-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3007194	No. 1, Bearing, Ball	None
P&WC	PT6A-25/ -25A	3032621	Bearing	None
P&WC	PT6A-25/ -25A	3007194	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3028003	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3101864-01	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3033481	Bearing	None
P&WC	PT6A-25/ -25A	3033459	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3073904-01	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3101864-01	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3009243	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3032623	Bearing	None
P&WC	PT6A-25/ -25A	3028006	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3101635-01	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3073901-01	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3006146	Bearing- Ball	None
P&WC	PT6A-25/ -25A	3032208	Bearing	None
P&WC	PT6A-25/ -25A	3006146	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3028004	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3102455-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3032208	Bearing	None
P&WC	PT6A-25/ -25A	3031717	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3102455-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3073900-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3010674	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3032209	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-25/ -25A	3010374	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3028005	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3031724	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3101636-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3037278	Bearing	None
P&WC	PT6A-25/ -25A	3112367-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3112368-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3112369-01	Bearing- Roller	None
P&WC	PT6A-25/ -25A	3073908-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3006146	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032208	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3006146	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3028004	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3102455-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032208	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3006146	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3031717	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3102455-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3073900-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3007194	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032621	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3007194	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3028003	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3101864-01	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3033481	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3033459	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3073904-01	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3009243	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032623	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3009243	Beaing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3028006	Beaing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3101635-01	Beaing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032623	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3073901-01	Bearing- Ball	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3006146	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032208	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3028004	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3102455-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3031717	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3073900-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3032209	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3010674	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3028005	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3031724	Bearing- Roller	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6-34/ -34AG/ -34B/ -36	3101636-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3037278	Bearing	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3112367-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3112368-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3112369-01	Bearing- Roller	None
P&WC	PT6-34/ -34AG/ -34B/ -36	3073908-01	Bearing- Roller	None
P&WC	PT6A-35	3032208	Bearing	None
P&WC	PT6A-35	3028004	Bearing- Roller	None
P&WC	PT6A-35	3102455-01	Bearing	None
P&WC	PT6A-35	3073900-01	Bearing- Roller	None
P&WC	PT6A-35	3033481	Bearing	None
P&WC	PT6A-35	3007194	Bearing- Ball	None
P&WC	PT6A-35	3033459	Bearing- Ball	None
P&WC	PT6A-35	3101864-01	Bearing- Ball	None
P&WC	PT6A-35	3073904-01	Bearing- Ball	None
P&WC	PT6A-35	3032623	Bearing	None
P&WC	PT6A-35	3009243	Bearing- Ball	None
P&WC	PT6A-35	3028006	Bearing- Ball	None
P&WC	PT6A-35	3101635-01	Bearing- Ball	None
P&WC	PT6A-35	3073901-01	Bearing- Ball	None
P&WC	PT6A-35	3032208	Bearing	None
P&WC	PT6A-35	3028004	Bearing- Roller	None
P&WC	PT6A-35	3102455-01	Bearing- Roller	None
P&WC	PT6A-35	3073900-01	Bearing- Roller	None
P&WC	PT6A-35	3037278	Bearing	None
P&WC	PT6A-35	3112367-01	Bearing- Roller	None
P&WC	PT6A-35	3112368-01	Bearing- Roller	None
P&WC	PT6A-35	3112369-01	Bearing- Roller	None
P&WC	PT6A-35	3073908-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3006146	No. 2 Bearing, Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3006146	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3007194	No. 1 Bearing, Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3009243	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3010674	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3026892	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3028003	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3028004	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3028004	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3028005	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3030925	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3031683	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3031717	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3031717	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-38/ -41/ -42/ -42A	3031724	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3032208	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3032208	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3032209	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3032621	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3033459	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3033481	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3037278	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3610674	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3072788-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3072789-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3072810-01	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3072811-01	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3073900-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3073900-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3073908-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3101636-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3101864-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3102455-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3102455-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3109206-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3109209-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3109210-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112117-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112117-02	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112117-03	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112367-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112368-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112369-01	Bearing- Roller	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112696-01	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112696-02	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3112696-03	Bearing- Ball	None
P&WC	PT6A-38/ -41/ -42/ -42A	3119806-01	Bearing	None
P&WC	PT6A-38/ -41/ -42/ -42A	3119807-01	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3006146	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3006146	No. 3 Bearing, Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3007194	No. 1 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3009243	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3010674	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3026892	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3028004	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3028004	No. 3 Bearing, Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3028005	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3030925	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-45A/ -45B/ -45R	3031683	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3031717	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3031717	No. 3 Bearing, Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3031724	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3032208	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3032208	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3032209	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3032657	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3037278	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3072788-01	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3072789-01	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3072810-01	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3072811-01	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3073900-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3073900-01	No. 3 Bearing, Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3073908-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3101636-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3101649-01	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3102455-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3102455-01	No. 3 Bearing, Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3109209-01	No. 1 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3109210-01	Bearing- Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3109210-01	No. 4 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112117-01	No. 1 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112117-02	No. 1 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112117-03	No. 1 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112367-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3112368-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3112369-01	Bearing- Roller	None
P&WC	PT6A-45A/ -45B/ -45R	3112696-01	No. 4 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112696-02	No. 4 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3112696-03	No. 4 Bearing, Ball	None
P&WC	PT6A-45A/ -45B/ -45R	3119806-01	Bearing	None
P&WC	PT6A-45A/ -45B/ -45R	3119807-01	Bearing	None
P&WC	PT6A-50	3006146	Bearing- Roller	None
P&WC	PT6A-50	3006146	Bearing- Roller	None
P&WC	PT6A-50	3007194	Bearing- Ball	None
P&WC	PT6A-50	3010374	Bearing- Roller	None
P&WC	PT6A-50	3010674	Bearing- Roller	None
P&WC	PT6A-50	3026892	Bearing- Ball	None
P&WC	PT6A-50	3028003	Bearing- Ball	None
P&WC	PT6A-50	3028004	Bearing- Roller	None
P&WC	PT6A-50	3028004	Bearing- Roller	None
P&WC	PT6A-50	3028005	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-50	3030925	Bearing- Ball	None
P&WC	PT6A-50	3031683	Bearing- Ball	None
P&WC	PT6A-50	3031717	Bearing- Roller	None
P&WC	PT6A-50	3031717	Bearing- Roller	None
P&WC	PT6A-50	3031724	Bearing- Roller	None
P&WC	PT6A-50	3032208	Bearing	None
P&WC	PT6A-50	3032208	Bearing	None
P&WC	PT6A-50	3032209	Bearing- Roller	None
P&WC	PT6A-50	3032621	Bearing	None
P&WC	PT6A-50	3032657	Bearing	None
P&WC	PT6A-50	3037278	Bearing	None
P&WC	PT6A-50	3072788-01	Bearing- Ball	None
P&WC	PT6A-50	3072789-01	Bearing- Ball	None
P&WC	PT6A-50	3072810-01	Bearing	None
P&WC	PT6A-50	3072811-01	Bearing	None
P&WC	PT6A-50	3073900-01	Bearing- Roller	None
P&WC	PT6A-50	3073900-01	Bearing- Roller	None
P&WC	PT6A-50	3073908-01	Bearing- Roller	None
P&WC	PT6A-50	3101636-01	Bearing- Roller	None
P&WC	PT6A-50	3101649-01	Bearing- Ball	None
P&WC	PT6A-50	3101864-01	Bearing- Ball	None
P&WC	PT6A-50	3102455-01	Bearing- Roller	None
P&WC	PT6A-50	3102455-01	Bearing- Roller	None
P&WC	PT6A-50	3109209-01	Bearing- Ball	None
P&WC	PT6A-50	3109210-01	Bearing- Ball	None
P&WC	PT6A-50	3109806-01	Bearing	None
P&WC	PT6A-50	3112117-01	Bearing	None
P&WC	PT6A-50	3112117-02	Bearing	None
P&WC	PT6A-50	3112117-03	Bearing- Ball	None
P&WC	PT6A-50	3112367-01	Bearing- Roller	None
P&WC	PT6A-50	3112368-01	Bearing- Roller	None
P&WC	PT6A-50	3112369-01	Bearing- Roller	None
P&WC	PT6A-50	3112696-01	Bearing- Ball	None
P&WC	PT6A-50	3112696-03	Bearing- Ball	None
P&WC	PT6A-50	3119806-01	Bearing	None
P&WC	PT6A-50	3119807-01	Bearing	None
P&WC	PT6A-50	3119807-01	Bearing	None
P&WC	PT6A-52	3032208	Bearing	None
P&WC	PT6A-52	3028004	Bearing- Roller	None
P&WC	PT6A-52	3028004	Bearing- Roller	None
P&WC	PT6A-52	3032208	Bearing	None
P&WC	PT6A-52	3037278	Bearing	None
P&WC	PT6A-52	3072788-01	Bearing- Ball	None
P&WC	PT6A-52	3072789-01	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-52	3072810-01	Bearing	None
P&WC	PT6A-52	3072811-01	Bearing	None
P&WC	PT6A-52	3073900-01	Bearing- Roller	None
P&WC	PT6A-52	3073900-01	Bearing- Roller	None
P&WC	PT6A-52	3073908-01	Bearing- Roller	None
P&WC	PT6A-52	3102455-01	Bearing- Roller	None
P&WC	PT6A-52	3102455-01	Bearing- Roller	None
P&WC	PT6A-52	3112117-03	Bearing- Ball	None
P&WC	PT6A-52	3112367-01	Bearing- Roller	None
P&WC	PT6A-52	3112368-01	Bearing- Roller	None
P&WC	PT6A-52	3112369-01	Bearing- Roller	None
P&WC	PT6A-52	3112696-03	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3032208	Bearing	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3006146	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3006164	No. 2, Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3010674	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3026892	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3028004	No. 2, Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3028004	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3028005	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3030925	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3031683	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3031717	No. 2, Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3031717	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3031724	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3032208	Bearing	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3032209	Bearing	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3032657	Bearing	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3037278	Bearing	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3072788-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3072789-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3072810-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3072811-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3073900-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3073900-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3073908-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3101636-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3101649-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3102455-01	No. 2, Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3102455-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3109209-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3109210-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112117-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112117-02	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112117-03	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112367-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112368-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112369-01	Bearing- Roller	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112696-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112696-02	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3112696-03	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3119806-01	Bearing- Ball	None
P&WC	PT6A-60/ -60A/ -60AG/ -61	3119807-01	Bearing	None
P&WC	PW100	3104543-01	No. 1 Bearing	None
P&WC	PW100	3037233 (IC)	No. 1 Bearing	None
P&WC	PW100	3104543-01	No. 1 Bearing	None
P&WC	PW100	3111620-01	No. 1 Bearing	None
P&WC	PW100	3104544-01	No. 2 Bearing	None
P&WC	PW100	3036767(IC)	No. 2 Bearing	None
P&WC	PW100	3104544-01	No. 2 Bearing	None
P&WC	PW100	3107845-01	No. 2 Bearing	None
P&WC	PW100	3104545-01	No. 2 Bearing	None
P&WC	PW100	3104545-02	No. 3 Bearing	None
P&WC	PW100	3036768(IC)	No. 3 Bearing	None
P&WC	PW100	3111453-01	No. 3 Bearing	None
P&WC	PW100	3111619-01	No. 3 Bearing	None
P&WC	PW100	3111943-01	No. 3 Bearing	None
P&WC	PW100	3105242-01	No. 3 Bearing	None
P&WC	PW100	3111943-01	No. 3 Bearing	None
P&WC	PW100	3110723-01	No. 3 Bearing	None
P&WC	PW100	3112489-01	No. 3 Bearing	None
P&WC	PW100	3072813-01(IC)	No. 3 Bearing	None
P&WC	PW100	3112489-01	No. 3 Bearing	None
P&WC	PW100	3072790-01	No. 3 Bearing	None
P&WC	PW100	3104546-01	No. 4 Bearing	None
P&WC	PW100	3037234(IC)	No. 4 Bearing	None
P&WC	PW100	3104546-01	No. 4 Bearing	None
P&WC	PW100	3111618-01	No. 4 Bearing	None
P&WC	PW100	3040444(IC)	No. 4 Bearing	None
P&WC	PW100	3111618-01	No. 4 Bearing	None
P&WC	PW100	3040444(IC)	No. 4 Bearing	None
P&WC	PW100	3111618-01	No. 4 Bearing	None
P&WC	PW100	3117748-01	No. 4 Bearing	None
P&WC	PW100	3104547-01	No. 5 Bearing	None
P&WC	PW100	3036067(RWK)	No. 5 Bearing	None
P&WC	PW100	3108152-01	No. 5 Bearing	None
P&WC	PW100	3113276-01	No. 5 Bearing	None
P&WC	PW100	3113623-01	No. 5 Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PW100	3121031-01	No. 5 Bearing	None
P&WC	PW100	3121706-01	No. 5 Bearing	None
P&WC	PW100	3121708-01	No. 5 Bearing	None
P&WC	PW100	3105116-01	No. 6 Bearing	None
P&WC	PW100	3036770(IC)	No. 6 Bearing	None
P&WC	PW100	3105116-01	No. 6 Bearing	None
P&WC	PW100	3107849-01	No. 6 Bearing	None
P&WC	PW100	3041035(IC)	No. 6 Bearing	None
P&WC	PW100	3105116-02	No. 6 Bearing	None
P&WC	PW100	3107849-02	No. 6 Bearing	None
P&WC	PW100	3041176(IC)	No. 6 Bearing	None
P&WC	PW100	3105116-02	No. 6 Bearing	None
P&WC	PW100	3107849-03	No. 6 Bearing	None
P&WC	PW100	3105117-01	No. 7 Bearing	None
P&WC	PW100	3037235(IC)	No. 7 Bearing	None
P&WC	PW100	3105117-01	No. 7 Bearing	None
P&WC	PW100	3107850-01	No. 7 Bearing	None
P&WC	PW100	3059373-01	No. 7 Bearing	None
P&WC	PW100	3073907-01	No. 7 Bearing	None
P&WC	PW100	3106847-01	No. 8/9 Bearing	None
P&WC	PW100	3037212(IC)	No. 8/9 Bearing	None
P&WC	PW100	3106847-01	No. 8/9 Bearing	None
P&WC	PW100	3111927-01	No. 8/9 Bearing	None
P&WC	PW100	3101175-01	No. 8/9 Bearing	None
P&WC	PW100	3036904(IC)	No. 8/9 Bearing	None
P&WC	PW100	3101175-01	No. 8/9 Bearing	None
P&WC	PW100	3111497-01	No. 8/9 Bearing	None
P&WC	PW100	3101191-01	No. 10 Bearing	None
P&WC	PW100	3101192-01	No. 11 Bearing	None
P&WC	PW100	3036903(IC)	No. 11 Bearing	None
P&WC	PW100	3101192-01	No. 11 Bearing	None
P&WC	PW100	3107636-01	No. 11 Bearing	None
P&WC	PW100	3106846-01	No. 11 Bearing	None
P&WC	PW100	3037210(IC)	No. 11 Bearing	None
P&WC	PW100	3106846-01	No. 11 Bearing	None
P&WC	PW100	3111928-01	No. 11 Bearing	None
P&WC	PW100	3101194-01	No. 12 Bearing	None
P&WC	PW100	3036902(IC)	No. 12 Bearing	None
P&WC	PW100	3101194-01	No. 12 Bearing	None
P&WC	PW100	3107635-01	No. 12 Bearing	None
P&WC	PW100	3106846-01	No. 12 Bearing	None
P&WC	PW100	3037210(IC)	No. 12 Bearing	None
P&WC	PW100	3106846-01	No. 12 Bearing	None
P&WC	PW100	3111928-01	No. 12 Bearing	None
P&WC	PW100	3101202-01	No. 13/14 Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PW100	3037217(IC)	No. 13/14 Bearing	None
P&WC	PW100	3101202-01	No. 13/14 Bearing	None
P&WC	PW100	3109243-01	No. 13/14 Bearing	None
P&WC	PW100	3102144-01	No. 13/14 Bearing	None
P&WC	PW100	3036959(IC)	No. 13/14 Bearing	None
P&WC	PW100	3102144-01	No. 13/14 Bearing	None
P&WC	PW100	3109245-01	No. 13/14 Bearing	None
P&WC	PW100	3104818-01	No. 13/14 Bearing	None
P&WC	PW100	3037213(IC)	No. 13/14 Bearing	None
P&WC	PW100	3104818-01	No. 13/14 Bearing	None
P&WC	PW100	3111930-01	No. 13/14 Bearing	None
P&WC	PW100	3101202-01	No. 15 Bearing	None
P&WC	PW100	3107033-01	No. 15 Bearing	None
P&WC	PW100	3037218(IC)	No. 15 Bearing	None
P&WC	PW100	3107033-01	No. 15 Bearing	None
P&WC	PW100	3109244-01	No. 15 Bearing	None
P&WC	PW100	3106213-01	No. 15 Bearing	None
P&WC	PW100	3037203(IC)	No. 15 Bearing	None
P&WC	PW100	3106213-01	No. 15 Bearing	None
P&WC	PW100	3111931-01	No. 15 Bearing	None
P&WC	PW100	3102138-01	No. 16/17 Bearing	None
P&WC	PW100	3100623-01	No. 18 Bearing	None
P&WC	PW100	3056074-01(IC)	No. 18 Bearing	None
P&WC	PW100	3100623-01	No. 18 Bearing	None
P&WC	PW100	3056073-01	No. 18 Bearing	None
P&WC	PW100	3104062-01	No. 18 Bearing	None
P&WC	PW100	3104817-01	No. 18 Bearing	None
P&WC	PW100	3037216(IC)	No. 18 Bearing	None
P&WC	PW100	3104817-01	No. 18 Bearing	None
P&WC	PW100	3111929-01	No. 18 Bearing	None
P&WC	PW100	3037264(IC)	No. 18 Bearing	None
P&WC	PW100	3112269-01	No. 18 Bearing	None
P&WC	PW100	3112355-01	No. 18 Bearing	None
P&WC	PW100	3039269(IC)	No. 18 Bearing	None
P&WC	PW100	3114774-01	No. 18 Bearing	None
P&WC	PW100	3114775-01	No. 18 Bearing	None
P&WC	PW100	3102136-01	No. 19 Bearing	None
P&WC	PW100	3107032-01	No. 19 Bearing	None
P&WC	PW100	3054622-01(IC)	No. 19 Bearing	None
P&WC	PW100	3054621-01	No. 19 Bearing	None
P&WC	PW100	3107032-01	No. 19 Bearing	None
P&WC	PW100	3107090-01	No. 19 Bearing	None
P&WC	PW100	3112449-01	No. 19 Bearing	None
P&WC	PW100	3054215-01(IC)	No. 19 Bearing	None
P&WC	PW100	3107090-01	No. 19 Bearing	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PW100	3112449-01	No. 19 Bearing	None
P&WC	PW100	3106212-01	No. 19 Bearing	None
P&WC	PW100	3037215(IC)	No. 19 Bearing	None
P&WC	PW100	3106212-01	No. 19 Bearing	None
P&WC	PW100	3111932-01	No. 19 Bearing	None
P&WC	PW100	3112354-01	No. 19 Bearing	None
P&WC	PW100	3038309(IC)	No. 19 Bearing	None
P&WC	PW100	3112354-01	No. 19 Bearing	None
P&WC	PW100	3113781-01	No. 19 Bearing	None
P&WC	PW100	3038309(IC)	No. 19 Bearing	None
P&WC	PW100	3113781-01	No. 19 Bearing	None
P&WC	PW100	3114375-01	No. 19 Bearing	None
P&WC	PW100	3032209(IC)	No. 20/21 Bearings	None
P&WC	PW100	3010674	No. 20/21 Bearings	None
P&WC	PW100	3028005	No. 20/21 Bearings	None
P&WC	PW100	3031724	No. 20/21 Bearings	None
P&WC	PW100	3101636-01	No. 20/21 Bearings	None
P&WC	PW100	3037278(IC)	No. 20/21 Bearings	None
P&WC	PW100	3112367-01	No. 20/21 Bearings	None
P&WC	PW100	3112368-01	No. 20/21 Bearings	None
P&WC	PW100	3112369-01	No. 20/21 Bearings	None
P&WC	PW100	3073908-01	No. 20/21 Bearings	None
P&WC	PW100	3101362-01	No. 22 Bearing	None
P&WC	PW100	3036905(IC)	No. 22 Bearing	None
P&WC	PW100	3101362-01	No. 22 Bearing	None
P&WC	PW100	3107449-01	No. 22 Bearing	None
P&WC	PW100	3104907-01	No. 22 Bearing	None
P&WC	PW100	3037346(IC)	No. 22 Bearing	None
P&WC	PW100	3104907-01	No. 22 Bearing	None
P&WC	PW100	3105760-01	No. 22 Bearing	None
P&WC	PW100	3032209(IC)	No. 23 Bearing	None
P&WC	PW100	3010674	No. 23 Bearing	None
P&WC	PW100	3028005	No. 23 Bearing	None
P&WC	PW100	3031724	No. 23 Bearing	None
P&WC	PW100	3101636-01	No. 23 Bearing	None
P&WC	PW100	3037278(IC)	No. 23 Bearing	None
P&WC	PW100	3112367-01	No. 23 Bearing	None
P&WC	PW100	3112368-01	No. 23 Bearing	None
P&WC	PW100	3112369-01	No. 23 Bearing	None
P&WC	PW100	3073908-01	No. 23 Bearing	None
P&WC	PW100	3101362-01	No. 23 Bearing	None
P&WC	PW100	3036905(IC)	No. 23 Bearing	None
P&WC	PW100	3101362-01	No. 23 Bearing	None
P&WC	PW100	3107449-01	No. 23 Bearing	None
P&WC	PW100	3032209(IC)	No. 24/26 Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PW100	3010674	No. 24/26 Bearing	None
P&WC	PW100	3028005	No. 24/26 Bearing	None
P&WC	PW100	3031724	No. 24/26 Bearing	None
P&WC	PW100	3101636-01	No. 24/26 Bearing	None
P&WC	PW100	3037278(IC)	No. 24/26 Bearing	None
P&WC	PW100	3112367-01	No. 24/26 Bearing	None
P&WC	PW100	3112368-01	No. 24/26 Bearing	None
P&WC	PW100	3112369-01	No. 24/26 Bearing	None
P&WC	PW100	3073908-01	No. 24/26 Bearing	None
P&WC	PW100	3036906(IC)	No. 24 Bearing	None
P&WC	PW100	3101393-01	No. 24 Bearing	None
P&WC	PW100	3107450-01	No. 24 Bearing	None
P&WC	PW100	3103579-01	No. 25 Bearing	None
P&WC	PW100	3101393-01	No. 25 Bearing	None
P&WC	PW100	3036906(IC)	No. 25 Bearing	None
P&WC	PW100	3101393-01	No. 25 Bearing	None
P&WC	PW100	3107450-01	No. 25 Bearing	None
P&WC	PW100	3101371-01	No. 26/27 Bearing	None
P&WC	PW100	3036907(IC)	No. 26/27 Bearing	None
P&WC	PW100	3101371-01	No. 26/27 Bearing	None
P&WC	PW100	3109372-01	No. 26/27 Bearing	None
P&WC	PW100	3072793-01	No. 26/27 Bearing	None
P&WC	PW100	3032625(IC)	No. 28 Bearing	None
P&WC	PW100	3010771	No. 28 Bearing	None
P&WC	PW100	3100630-01	No. 28 Bearing	None
P&WC	PW100	3101630-01	No. 28 Bearing	None
P&WC	PW100	3107496-01	No. 28 Bearing	None
P&WC	PW100	3101393-01	No. 28 Bearing	None
P&WC	PW100	3036906(IC)	No. 28 Bearing	None
P&WC	PW100	3101393-01	No. 28 Bearing	None
P&WC	PW100	3107450-01	No. 28 Bearing	None
P&WC	PW100	3101394-01	No. 30 Bearing	None
P&WC	PW100	3106684-01	No. 30 Bearing	None
P&WC	PW100	3038447(IC)	No. 30 Bearing	None
P&WC	PW100	3106684-01	No. 30 Bearing	None
P&WC	PW100	3108720-01	No. 30 Bearing	None
P&WC	PW100	3072794-01	No. 30 Bearing	None
P&W	PW4000 (PW4052-4062)	50A022	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A045	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50A046	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50A048	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50A092	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A093	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A095	No. 2 Bearing, Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW4000 (PW4052-4062)	50A096	No. 2 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50A097	No. 2 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50A126	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A127	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A128	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50A466	No. 2 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50A467	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50B108	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B109	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B110	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B114	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B233	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B234	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B235	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B797	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50B798	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	50G010	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G011	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G013	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G113	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G114	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G115	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G399	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G401	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G402	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G403	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G404	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G405	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G406	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G407	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G630	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G631	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G632	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G633	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	50G634	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50G865	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G866	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G868	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50G983	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	50P000	No. 4 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50P001	No. 4 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50P005	No. 4 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50P084	No. 4 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50P395	No. 4 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	50R022	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW4000 (PW4052-4062)	50R023	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	51A653	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51A654	No. 2 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	51A726	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51B156	No. 1 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	51G986	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51G987	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51G988	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51G989	No. 1.5 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	51G990	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G991	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G992	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G994	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G995	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G996	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G997	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	51G998	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	51G999	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	52A115	No. 3 Bearing, Roller	None
P&W	PW4000 (PW4052-4062)	52G000	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	52G001	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	52G002	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	52G003	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	52G004	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	52G005	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	52G006	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	52G007	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	52G045	No. 2 Bearing, Ball	None
P&W	PW4000 (PW4052-4062)	52G246	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	70R019	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R020	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R022	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R023	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R024	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R032	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R033	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R034	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R218	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R219	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R222	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R223	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R224	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R225	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R268	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R269	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW4000 (PW4052-4062)	70R270	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R271	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R538	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	70R598	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R599	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R601	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R602	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R619	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R620	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R621	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R622	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R723	Bearing	None
P&W	PW4000 (PW4052-4062)	70R780	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R781	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R782	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	70R783	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	71R021	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	71R024	Bearing- Roller	None
P&W	PW4000 (PW4052-4062)	71R081	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	71R082	Bearing- Ball	None
P&W	PW4000 (PW4052-4062)	71R119	Bearing	None
P&W	PW2000 (ALL)	1A2442	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2443	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2444	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2445	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	1A2446	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	1A2447	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	1A2448	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2449	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2450	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1A2456	No. 5 Bearing, Roller	None
P&W	PW2000 (ALL)	1A2457	No. 5 Bearing, Roller	None
P&W	PW2000 (ALL)	1A2458	No. 5 Bearing, Roller	None
P&W	PW2000 (ALL)	1A9843	No. 4 Bearing, Roller	None
P&W	PW2000 (ALL)	1A9844	No. 4 Bearing, Roller	None
P&W	PW2000 (ALL)	1A9845	No. 4 Bearing, Roller	None
P&W	PW2000 (ALL)	1B2009	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2010	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2011	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2246	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2249	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2747	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2748	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2749	No. 1 Bearing, Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW2000 (ALL)	1B5890	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	1B6015	Bearing	None
P&W	PW2000 (ALL)	1B6016	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6018	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6019	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6077	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6078	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6538	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	1B7111	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	7T6200	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6202	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6210	Bearing	None
P&W	PW2000 (ALL)	7T6212	Bearing	None
P&W	PW2000 (ALL)	7T6230	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6260	Bearing	None
P&W	PW2000 (ALL)	7T6270	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6280	Bearing	None
P&W	PW2000 (ALL)	7T6700	Bearing-Roller	None
P&W	PW2000 (ALL)	7T6701	Bearing	None
P&W	PW2000 (ALL)	7T6810	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6812	Bearing- Ball	None
P&W	PW2000 (ALL)	7T6910	Bearing	None
P&W	PW2000 (ALL)	7T6912	Bearing	None
P&W	PW2000 (ALL)	7T6920	Bearing	None
P&W	PW2000 (ALL)	7T6921	Bearing	None
P&W	PW2000 (ALL)	7T6940	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6941	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6950	Bearing	None
P&W	PW2000 (ALL)	7T6951	Bearing	None
P&W	PW2000 (ALL)	7T6960	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6961	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6970	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6971	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6980	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6981	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6990	Bearing	None
P&W	PW2000 (ALL)	7T6991	Bearing	None
P&W	PW2000 (ALL)	7T7010	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7013	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7020	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7023	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7030	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7033	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7050	Bearing- Ball	None
P&W	PW2000 (ALL)	7T7052	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW2000 (ALL)	7T7070	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7073	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7080	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7083	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7100	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7102	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7110	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7112	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7120	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7123	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7130	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7133	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7140	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7143	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7150	Bearing	None
P&W	PW2000 (ALL)	7T7151	Bearing	None
P&W	PW2000 (ALL)	7T7160	Bearing	None
P&W	PW2000 (ALL)	7T7161	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7163	Bearing- Roller	None
P&W	PW2000 (ALL)	7T7770	Bearing- Roller	None
P&W	PW2000 (ALL)	7T0060	Bearing	None
P&W	PW2000 (ALL)	7T0063	Bearing	None
P&W	PW2000 (ALL)	7T0074	Bearing	None
P&W	PW2000 (ALL)	7T0091	Bearing	None
P&W	PW2000 (ALL)	7T0092	Bearing	None
P&W	PW2000 (ALL)	7T0094	Bearing	None
P&W	PW2000 (ALL)	7T0095	Bearing	None
P&W	PW2000 (ALL)	7T0096	Bearing	None
P&W	PW2000 (ALL)	7T0097	Bearing	None
P&W	PW2000 (ALL)	7T0120	Bearing	None
P&W	PW2000 (ALL)	7T0121	Bearing	None
P&W	PW2000 (ALL)	7T0129	Bearing	None
P&W	PW2000 (ALL)	7T6290	Bearing- Ball	None
P&W	PW2000 (ALL)	1A2454	No. 4 Bearing, Roller	None
P&W	PW2000 (ALL)	1A3366	Bearing	None
P&W	PW2000 (ALL)	1A9843	Bearing- Roller	None
P&W	PW2000 (ALL)	1A9844	No. 4 Bearing, Roller	None
P&W	PW2000 (ALL)	1A9845	Bearing- Roller	None
P&W	PW2000 (ALL)	1A9927	Bearing	None
P&W	PW2000 (ALL)	1B1026	Bearing	None
P&W	PW2000 (ALL)	1B1027	Bearing	None
P&W	PW2000 (ALL)	1B1028	Bearing	None
P&W	PW2000 (ALL)	1B1029	Bearing	None
P&W	PW2000 (ALL)	1B2008	Bearing	None
P&W	PW2000 (ALL)	1B2223	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW2000 (ALL)	1B2246	No. 3 Bearing, Ball	None
P&W	PW2000 (ALL)	1B2746	Bearing	None
P&W	PW2000 (ALL)	1B5128	Bearing	None
P&W	PW2000 (ALL)	1B5129	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B5130	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B5131	No. 1 Bearing, Ball	None
P&W	PW2000 (ALL)	1B6537	Bearing	None
P&W	PW2000 (ALL)	1B6538	No. 2 Bearing, Roller	None
P&W	PW2000 (ALL)	7T0070	Bearing	None
P&W	PW2000 (ALL)	7T0072	Bearing	None
P&W	PW2000 (ALL)	7T0073	Bearing	None
P&W	PW2000 (ALL)	7T0077	Bearing	None
P&W	PW2000 (ALL)	7T0081	Bearing	None
P&W	PW2000 (ALL)	7T0101	Bearing	None
P&W	PW2000 (ALL)	7T0102	Bearing	None
P&W	PW2000 (ALL)	7T0103	Bearing	None
P&W	PW2000 (ALL)	7T0105	Bearing	None
P&W	PW2000 (ALL)	7T0107	Bearing	None
P&W	PW2000 (ALL)	7T0108	Bearing	None
P&W	PW2000 (ALL)	7T0110	Bearing	None
P&W	PW2000 (ALL)	7T0111	Bearing	None
P&W	PW2000 (ALL)	7T0112	Bearing	None
P&W	PW2000 (ALL)	7T6920	Bearing- Roller	None
P&W	PW2000 (ALL)	7T6921	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T13P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T19P01	Bearing- Ball	None
GE	CF34-8C, CF34-8E	4115T20P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T21P02	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T22P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T23P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T24P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T25P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4115T97P02	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4116T09P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4116T56P01	Bearing- Ball	None
GE	CF34-8C, CF34-8E	4116T57P01	Bearing- Roller	None
GE	CF34-8C, CF34-8E	4117T65P02	No. 5 Bearing, Roller	None
GE	CF34-8C, CF34-8E	4126T19P01	No. 1 Bearing, Ball	None
GE	CF34-8C, CF34-8E	4126T20P01	No. 2 Bearing, Roller	None
GE	CF34-8C	4126T21P01	No. 3 Bearing, Ball	None
GE	CF34-8C	4126T22P02	No. 4 Bearing, Roller	None
GE	CF34-8C, CF34-8E	4126T31P01	No. 1 Bearing, Ball	None
GE	CF34-8C, CF34-8E	4126T32P01	No. 2 Bearing, Roller	None
GE	CF34-8C	4126T33P01	No. 3 Bearing, Ball	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
GE	CF34-8C	4126T34P02	No. 4 Bearing, Roller	None
GE	CF34-8C	4126T38P01	No. 3 Bearing, Ball	None
GE	CF34-8C	4129T39P01	No. 3 Bearing, Ball	None
GE	CF34-8C, CF34-8E	4129T47P02	No. 4 Bearing, Roller	None
GE	CF34-8C, CF34-8E	4129T48P02	No. 4 Bearing, Roller	None
GE	CF34-8C, CF34-8E	4145T69P01	No. 3 Bearing, Ball	None
GE	CF34-8C, CF34-8E	4145T70P01	No. 3 Bearing, Ball	None
HWL	Vacuum Blower P/N 645172-1, -2	2785055-1	Bearing	None
HWL	Vacuum Blower P/N 645172-1, -2	2805159-1	Bearing	None
HWL	Model 36-150	358655-1	Bearing	Inspect and Relube
HWL	Model 36-150	361419-1	Bearing	Inspect and Relube
HWL	Model 36-150	3842004-1	Bearing	None
HWL	Model 131-9	3504433-1	Bearing	None
HWL	Model 131-9	3504435-1	Bearing	None
HWL	Model 131-9	3504741-1	Bearing	None
HWL	Model 131-9	3822478-1	Bearing- Roller	None
HWL	Model 131-9	3840242-1	Bearing- Roller	None
HWL	Model 131-9	3860865-1	Bearing- Roller	None
HWL	Model 331	3101405-1	Bearing	None
HWL	Model 331	358267	Bearing	None
HWL	Model 331	2860160-1	Bearing	None
HWL	Model 331	3101689-1	Bearing	None
HWL	Model 331	3102885-1	Bearing	None
HWL	Model 331	358268-1	Bearing	None
HWL	Model 331	358360-1	Bearing	None
HWL	Model 331	358361-1	Bearing	None
HWL	Model 331	358763-1	Bearing	None
HWL	Model 331	3605094-1	Bearing	None
HWL	Model 331	3613703-1	Bearing	None
HWL	Model 331	3613827-1	Bearing	None
HWL	Model 331	3614423-1	Bearing	None
HWL	Model 331	3822129-1	Bearing	None
HWL	Model 331	3860173-1	Bearing	None
HWL	Model 331	3860495-1	Bearing	None
HWL	Model 331	3860496-1	Bearing	None
HWL	GTCP331	3860496-1	Bearing- Ball	None
HWL	GTCP331	358024	Bearing- Ball	None
HWL	GTCP331	358027	Bearing- Ball	None
HWL	GTCP331	369144	Bearing- Roller	None
HWL	GTCP331	04DU04	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
HWL	GTCP331	06DU04	Bearing	None
HWL	GTCP331	3101092-1	Bearing- Roller	None
HWL	GTCP331	358457-1	Bearing- Ball	None
HWL	GTCP331	3605094-1	Bearing- Ball	None
HWL	GTCP331	3612701-1	Bearing	None
HWL	GTCP331	3612701-2	Bearing	None
HWL	GTCP331	3613827-1	Bearing- Ball	None
HWL	GTCP331	3614423-1	Bearing- Ball	None
HWL	GTCP331	3822071-1	Bearing- Ball	None
HWL	GTCP331	3822099-1	Bearing- Roller	None
HWL	GTCP331	3827098-1	Bearing	None
HWL	GTCP331	3827211-1	Bearing	None
HWL	GTCP331	3827221-1	Bearing	None
HWL	GTCP331	3827221-2	Bearing	None
HWL	GTCP331	3860158-1	Bearing- Roller	None
HWL	GTCP331	3860160-1	Bearing- Ball	None
HWL	GTCP331	3860173-1	Bearing- Roller	None
HWL	GTCP331	3860495-1	Bearing- Ball	None
HWL	GTCP331	892575-1	Bearing- Ball	None
HWL	GTCP331	892576-1	Bearing- Ball	None
HWL	GTCP331	3860540-1	Bearing	
HWL	GTCP331	3617585-001	Bearing	
HWL	GTCP331	3860853	Bearing	
HWL	Model 331-500B	3860832-2	Bearing	None
HWL	Model 331-500B	3616641-1	Bearing	None
HWL	Model 331-500B	3840124-3	Bearing	None
HWL	Model 331-500B	3840130-1	Bearing	None
HWL	Model 331-500B	3840228-2	Bearing	None
HWL	Model 331-500B	3840240-1	Bearing	None
HWL	Model 331-500B	3860831-1	Bearing	None
HWL	Model 331-500B	3860832-2	Bearing	None
HWL	Model 331-500B	3860833-1	Bearing	None
HWL	Model 331-500B	3860836-2	Bearing	None
HWL	Model 331-500B	3860837-1	Bearing	None
HWL	Model 331-500B	3860838-2	Bearing	None
HWL	Model 331-500B	3860839-2	Bearing	None
HWL	Model 331-500B	3860861-1	Bearing	None
HWL	Model 331-500B	3861160-1	Bearing	None
HWL	Model 331-500B	3861161-1	Bearing	None
HWL	Model 331-500B	3868035-2	Bearing	None
HWL	GTCP36-6	358206	Bearing- Ball	None
HWL	GTCP36-6	3072885-1	Bearing- Ball	None
HWL	GTCP36-6	358379-1	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
HWL	GTCP36-6	358388-1	Bearing- Ball	None
HWL	GTCP36-6	358402-1	Bearing- Ball	None
HWL	GTCP36-6	3601135-1	Bearing- Ball	None
HWL	GTCP85	358024	Bearing- Ball	None
HWL	GTCP85	358026	Bearing	None
HWL	GTCP85	358027	Bearing	None
HWL	GTCP85	373917	Bearing	None
HWL	GTCP85	352880	Bearing- Ball	None
HWL	GTCP85	358348	Bearing- Ball	None
HWL	GTCP85	358451	Bearing- Ball	None
HWL	GTCP85	358457	Bearing- Ball	None
HWL	GTCP85	358649	Bearing- Ball	None
HWL	GTCP85	358894	Bearing- Ball	None
HWL	GTCP85	3601027	Bearing- Ball	None
HWL	GTCP85	3609114	Bearing- Ball	None
HWL	GTCP85	373028	Bearing- Ball	None
HWL	GTCP85	40471	Bearing- Ball	None
HWL	GTCP85	52529	Bearing- Ball	None
HWL	GTCP85	56484	Bearing- Ball	None
HWL	GTCP85	56523	Bearing- Ball	None
HWL	GTCP85	56484	Bearing- Ball	None
HWL	GTCP85	71129	Bearing- Ball	None
HWL	GTCP85	73098	Bearing- Ball	None
HWL	GTCP85	523587	Bearing	None
HWL	GTCP85	693328	Bearing	None
HWL	GTCP85	693329	Bearing	None
HWL	GTCP85	358155	Bearing	None
HWL	GTCP85	358245	Bearing	None
HWL	GTCP85	369069	Bearing	None
HWL	GTCP85	372435	Bearing	None
HWL	GTCP85	71871	Bearing	None
HWL	GTCP85	74346	Bearing	None
HWL	GTCP85	202HX24	Bearing	None
HWL	GTCP85	358026WD	Bearing	None
HWL	GTCP85	358027WE	Bearing	None
HWL	GTCP85	358245-1	Bearing	None
HWL	GTCP85	358374-1	Bearing	None
HWL	GTCP85	358457-1	Bearing	None
HWL	GTCP85	358457-1WE	Bearing	None
HWL	GTCP85	358567-1	Bearing	None
HWL	GTCP85	358649-1	Bearing	None
HWL	GTCP85	358649-1WE	Bearing	None
HWL	GTCP85	3601027-1	Bearing	None
HWL	GTCP85	3601027-1WD	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
HWL	GTCP85	3601971-1	Bearing	None
HWL	GTCP85	3609114-1	Bearing	None
HWL	GTCP85	3614920-1	Bearing	None
HWL	GTCP85	3614920-1WD	Bearing	None
HWL	GTCP85	3615601-1	Bearing	None
HWL	GTCP85	373917WE	Bearing	Inspect and Relube
HWL	GTCP85	7202VAB	Bearing	Inspect and Relube
HWL	GTCP85	Q20202US5593	Bearing	Inspect and Relube
HWL	Model 700	358540-1	Bearing	None
HWL	Model 700	358629-1	Bearing	None
HWL	Model 700	358632-1	Bearing	None
HWL	Model 700	3600624-1	Bearing	None
HWL	Model 700	3600837-3	Bearing	None
HWL	Model 700	3603659-1	Bearing	None
HWL	Model 700	3603923-1	Bearing	None
HWL	Model 700	3604412-1	Bearing	None
HWL	Model 700	3604485-1	Bearing	None
HWL	Model 700	3605095-1	Bearing	None
HWL	Model 700	3610380-1	Bearing	None
HWL	Model 700	3610423-1	Bearing	None
HWL	Model 700	3610599-1	Bearing	None
HWL	Model 700	3611712-1	Bearing	None
HWL	Model 700	3613626-1	Bearing	None
HWL	Model 700	3614194-1	Bearing	None
HWL	Model 700	3614195-1	Bearing	None
HWL	Model 700	3840195-1	Bearing	None
HWL	Model 700	3860298-1	Bearing	None
Smiths	IDG Generator, PN 3301KGA	28/KLNJ- 3/8	Bearing	None
Smiths	IDG Generator, PN 3301KGA	N9426V3	Bearing	None
Smiths	IDG Generator, PN 3301KGA	BCP1311	Bearing	None
AOA	Vacuum Blower, PN 361178	361178	Bearing	None
Boeing	B707	BACB10C99 AYT	Bearing- Roller	None
Boeing	B707	MS28914-14C	Bearing- Roller	None
Boeing	B707	DAS14-48A14	Bearing	None
Boeing	B707	A14FHT	Bearing	None
Boeing	B707	DAS6-25BQ	Bearing	None
P&W	PW JT9D-7R4	559165	Bearing- Ball	None
P&W	PW JT9D-7R4	581459	Bearing- Ball	None
P&W	PW JT9D-7R4	599157	Bearing- Ball	None
P&W	PW JT9D-7R4	599163	Bearing- Ball	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW JT9D-7R4	599165	Bearing- Ball	None
P&W	PW JT9D-7R4	599170	Bearing- Ball	None
P&W	PW JT9D-7R4	599171	Bearing- Ball	None
P&W	PW JT9D-7R4	599178	Bearing- Roller	None
P&W	PW JT9D-7R4	599183	Bearing- Roller	None
P&W	PW JT9D-7R4	599188	Bearing-Roller	None
P&W	PW JT9D-7R4	599798	Bearing	None
P&W	PW JT9D-7R4	624029	Bearing	None
P&W	PW JT9D-7R4	651429	Bearing	None
P&W	PW JT9D-7R4	652208	Bearing	None
P&W	PW JT9D-7R4	655691	Bearing	None
P&W	PW JT9D-7R4	665793	Bearing	None
P&W	PW JT9D-7R4	679063	Bearing- Roller	None
P&W	PW JT9D-7R4	697064	Bearing- Roller	None
P&W	PW JT9D-7R4	697065	Bearing	None
P&W	PW JT9D-7R4	697066	Bearing- Roller	None
P&W	PW JT9D-7R4	697067	Bearing- Roller	None
P&W	PW JT9D-7R4	699057	Bearing- Roller	None
P&W	PW JT9D-7R4	699076	Bearing- Ball	None
P&W	PW JT9D-7R4	714064	Bearing- Roller	None
P&W	PW JT9D-7R4	735065	Bearing- Roller	None
P&W	PW JT9D-7R4	735168	Bearing- Roller	None
P&W	PW JT9D-7R4	754380	No. 2 Bearing	None
P&W	PW JT9D-7R4	754389	No. 2 Bearing	None
P&W	PW JT9D-7R4	754391	Bearing	None
P&W	PW JT9D-7R4	766578	No. 2 Bearing	None
P&W	PW JT9D-7R4	768637	Bearing	None
P&W	PW JT9D-7R4	771088	Bearing	None
P&W	PW JT9D-7R4	773227	Bearing- Roller	None
P&W	PW JT9D-7R4	779718	Bearing- Ball	None
P&W	PW JT9D-7R4	781983	Bearing-Roller	None
P&W	PW JT9D-7R4	781984	Bearing-Roller	None
P&W	PW JT9D-7R4	781985	Bearing- Ball	None
P&W	PW JT9D-7R4	781986	Bearing-Roller	None
P&W	PW JT9D-7R4	781989	Bearing- Roller	None
P&W	PW JT9D-7R4	781990	Bearing-Roller	None
P&W	PW JT9D-7R4	781991	Bearing- Roller	None
P&W	PW JT9D-7R4	781992	Bearing- Ball	None
P&W	PW JT9D-7R4	781993	Bearing- Ball	None
P&W	PW JT9D-7R4	782210	Bearing-Roller	None
P&W	PW JT9D-7R4	782211	Bearing- Roller	None
P&W	PW JT9D-7R4	782212	Bearing- Roller	None
P&W	PW JT9D-7R4	782213	Bearing- Roller	None
P&W	PW JT9D-7R4	782214	Bearing- Roller	None
P&W	PW JT9D-7R4	782215	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW JT9D-7R4	782216	Bearing- Roller	None
P&W	PW JT9D-7R4	782217	Bearing- Roller	None
P&W	PW JT9D-7R4	782219	Bearing- Roller	None
P&W	PW JT9D-7R4	782220	Bearing- Roller	None
P&W	PW JT9D-7R4	782552	Bearing- Ball	None
P&W	PW JT9D-7R4	782553	Bearing- Roller	None
P&W	PW JT9D-7R4	782716	Bearing- Roller	None
P&W	PW JT9D-7R4	782717	Bearing- Roller	None
P&W	PW JT9D-7R4	782918	Bearing- Ball	None
P&W	PW JT9D-7R4	783006	Bearing- Ball	None
P&W	PW JT9D-7R4	783502	Bearing	None
P&W	PW JT9D-7R4	783503	Bearing	None
P&W	PW JT9D-7R4	783504	Bearing	None
P&W	PW JT9D-7R4	783505	Bearing	None
P&W	PW JT9D-7R4	783507	Bearing	None
P&W	PW JT9D-7R4	783508	Bearing	None
P&W	PW JT9D-7R4	783509	Bearing	None
P&W	PW JT9D-7R4	783510	Bearing- Roller	None
P&W	PW JT9D-7R4	783511	Bearing	None
P&W	PW JT9D-7R4	783512	Bearing	None
P&W	PW JT9D-7R4	783513	Bearing	None
P&W	PW JT9D-7R4	783514	Bearing	None
P&W	PW JT9D-7R4	783515	Bearing	None
P&W	PW JT9D-7R4	783516	Bearing	None
P&W	PW JT9D-7R4	783518	Bearing	None
P&W	PW JT9D-7R4	783519	Bearing	None
P&W	PW JT9D-7R4	783520	Bearing	None
P&W	PW JT9D-7R4	784350	Bearing-Roller	None
P&W	PW JT9D-7R4	785103	No. 2 Bearing	None
P&W	PW JT9D-7R4	785104	No. 2 Bearing	None
P&W	PW JT9D-7R4	785154	Bearing-Roller	None
P&W	PW JT9D-7R4	785608	Bearing	None
P&W	PW JT9D-7R4	798895	Bearing	None
P&W	PW JT9D-7R4	798896	Bearing- Roller	None
P&W	PW JT9D-7R4	798897	Bearing- Roller	None
P&W	PW JT9D-7R4	799374	Bearing	None
P&W	PW JT9D-7R4	799375	Bearing- Ball	None
P&W	PW JT9D-7R4	800094	Bearing- Ball	None
P&W	PW JT9D-7R4	802098	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	802099	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	803993	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	804106	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	804109	Bearing	None
P&W	PW JT9D-7R4	804110	Bearing- Roller	None
P&W	PW JT9D-7R4	804111	Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW JT9D-7R4	804760	Bearing- Roller	None
P&W	PW JT9D-7R4	810641	No. 3 Bearing- Roller	None
P&W	PW JT9D-7R4	811936	Bearing- Roller	None
P&W	PW JT9D-7R4	815509	Bearing- Ball	None
P&W	PW JT9D-7R4	815510	Bearing- Roller	None
P&W	PW JT9D-7R4	815511	Bearing- Roller	None
P&W	PW JT9D-7R4	815512	Bearing-Roller	None
P&W	PW JT9D-7R4	815513	Bearing- Ball	None
P&W	PW JT9D-7R4	815514	Bearing- Roller	None
P&W	PW JT9D-7R4	815515	Bearng- Roller	None
P&W	PW JT9D-7R4	815516	Bearing- Roller	None
P&W	PW JT9D-7R4	815517	Bearing- Roller	None
P&W	PW JT9D-7R4	815518	Bearing- Roller	None
P&W	PW JT9D-7R4	815521	Bearing- Roller	None
P&W	PW JT9D-7R4	815522	Bearing- Roller	None
P&W	PW JT9D-7R4	815523	Bearing	None
P&W	PW JT9D-7R4	815524	Bearing	None
P&W	PW JT9D-7R4	815840	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	X599157	Bearing- Ball	None
P&W	PW JT9D-7R4	X612014	Bearing- Roller	None
P&W	PW JT9D-7R4	X693021	No. 3 Bearing- Roller	None
P&W	PW JT9D-7R4	X735176	Bearing- Ball	None
P&W	PW JT9D-7R4	X735178	No. 3 Bearing- Roller	None
P&W	PW JT9D-7R4	X743032	Bearing	None
P&W	PW JT9D-7R4	X743033	Bearing- Roller	None
P&W	PW JT9D-7R4	X743034	Bearing- Roller	None
P&W	PW JT9D-7R4	X754372	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	X754373	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	X754377	No. 1 Bearing	None
P&W	PW JT9D-7R4	X754380	Bearing- Ball	None
P&W	PW JT9D-7R4	X771087	Bearing	None
P&W	PW JT9D-7R4	X773517	Bearing	None
P&W	PW JT9D-7R4	X779717	Bearing- Roller	None
P&W	PW JT9D-7R4	X781987	Bearing- Roller	None
P&W	PW JT9D-7R4	X783506	Bearing	None
P&W	PW JT9D-7R4	X783517	Bearing	None
P&W	PW JT9D-7R4	X797248	No. 3 Bearing	None
P&W	PW JT9D-7R4	X800105	Bearing- Roller	None
P&W	PW JT9D-7R4	X802946	No. 3 Bearing- Roller	None
P&W	PW JT9D-7R4	X803189	No. 1 Bearing	None
P&W	PW JT9D-7R4	X803190	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	X803191	No. 1 Bearing- Ball	None
P&W	PW JT9D-7R4	X804760	Bearing- Roller	None
P&W	PW JT9D-7R4	X805944	No. 3 Bearing	None
P&W	PW JT9D-7R4	X805945	No. 3 Bearing- Roller	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&W	PW JT9D-7R4	X811936	Bearing- Roller	None
P&W	PW JT9D-7R4	Z785727	No. 1 Bearing	None
P&W	PW JT9D-7R4	Z785728	No. 1 Bearing	None
P&W	PW JT9D-7R4	Z785734	Bearing	None
P&W	PW JT9D-7R4	Z785737	Bearing	None
P&W	PW JT9D-7R4	Z792190	No. 1 Bearing	None
P&W	PW JT9D-7R4	Z819095	No. 1 Bearing	None
P&W	PW JT9D-7R4	Z819806	No. 1 Bearing	None
P&WC	PW901A/PW901C	3910005-01	Bearing	None
P&WC	PW901A/PW901C	3900314	Bearing	None
P&WC	PW901A/PW901C	3900480	Bearing	None
P&WC	PW901A/PW901C	3900513	Bearing	None
P&WC	PW901A/PW901C	3900631	Bearing	None
P&WC	PW901A/PW901C	3900660	Bearing	None
P&WC	PW901A/PW901C	3900668	Bearing	None
P&WC	PW901A/PW901C	3910492-01	Bearing	None
P&WC	PW901A/PW901C	3910790-01	Bearing	None
P&WC	PW901A/PW901C	3911985-01	Bearing	None
P&WC	PW901A/PW901C	3900924-01	Bearing	None
P&WC	PW901A/PW901C	3900953-02	Bearing	None
P&WC	PW901A/PW901C	3900954-01	Bearing	None
P&WC	PW901A/PW901C	3901957-01	Bearing	None
P&WC	PW901A/PW901C	3901959-01	Bearing	None
P&WC	PW901A/PW901C	3910006-01	Bearing	None
P&WC	PW901A/PW901C	3910007-01	Bearing	None
P&WC	PW901A/PW901C	3910008-01	Bearing	None
P&WC	PW901A/PW901C	3910011-01	Bearing	None
P&WC	PW901A/PW901C	3910012-01	Bearing	None
P&WC	PW901A/PW901C	3910015-01	Bearing	None
P&WC	PW901A/PW901C	3910016-01	Bearing	None
P&WC	PW901A/PW901C	3910017-01	Bearing	None
P&WC	PW901A/PW901C	3910492-01	Bearing	None
P&WC	PW901A/PW901C	3910496-01	Bearing	None
P&WC	PW901A/PW901C	3910790-01	Bearing	None
P&WC	PW901A/PW901C	3910804-01	Bearing	None
P&WC	PW901A/PW901C	3911051-01	Bearing	None
P&WC	PW901A/PW901C	3911170-01	Bearing	None
P&WC	PW901A/PW901C	3911256-01	Bearing	None
P&WC	PW901A/PW901C	3911415-01	Bearing	None
P&WC	PW901A/PW901C	3911431-01	Bearing	None
P&WC	PW901A/PW901C	3911432-01	Bearing	None
P&WC	PW901A/PW901C	3911938-01	Bearing	None
P&WC	PW901A/PW901C	3911939-01	Bearing	None
P&WC	PW901A/PW901C	3911985-01	Bearing	None



# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
P&WC	PW901A/PW901C	3911986-01	Bearing	None
P&WC	PW901A/PW901C	3912218-01	Bearing	None
IAE	V-2500 A1-A5	4T0283	Bearing	None
HWL	Accessory	3502689-1	Bearing	None
HWL	Accessory	3502087-1	Bearing	None
HWL	Accessory	3502571-1	Bearing	None
HWL	Accessory	3502858-1	Bearing	None
HWL	Accessory	3177861-2	Bearing	None
HWL	Accessory	3103333-3	Bearing	None
HWL	Accessory	3502087-2	Bearing	None
HWL	Accessory	3502411-1	Bearing	None
HWL	Accessory	3502428-1	Bearing	None
HWL	Accessory	3502224-1	Bearing	None
HWL	Accessory	3501731-1	Bearing	None
HWL	Accessory	3502129-1	Bearing	None
HWL	Accessory	365366-1	Bearing	None
HWL	Accessory	3860835-2	Bearing	None
HWL	Accessory	3840242-1	Bearing	None
HWL	Accessory	4165313-3	Bearing	None
HWL	Accessory	4165315-4	Bearing	None
HWL	Accessory	4165317-4	Bearing	None
HWL	Accessory	4648317055	Bearing	None
HWL	Accessory	4648317047	Bearing	None
HWL	Accessory	4648316034	Bearing	None
HWL	Accessory	4648316029	Bearing	None
HWL	Accessory	4648302335	Bearing	None
HWL	Accessory	4648317048	Bearing	None
HWL	Accessory	81205761	Bearing	None
BELL	Model 206/Accessory	206-040-002-005	Bearing	None
BELL	Model 206/Accessory	206-040-002-013	Bearing	None
BELL	Model 206/Accessory	206-040-002-015	Bearing	None
BELL	Model 206/Accessory	206-040-002-025	Bearing	None
BELL	Model 206/Accessory	206-040-002-027	Bearing	None
BELL	Model 206/Accessory	206-040-002-029	Bearing	None
BELL	Model 206/Accessory	206-040-002-115	Bearing	None
BELL	Model 206/Accessory	206-040-004-003	Bearing	None
BELL	Model 206/Accessory	206-040-004-005	Bearing	None
BELL	Model 206/Accessory	206-040-004-101	Bearing	None
BELL	Model 206/Accessory	206-040-004-103	Bearing	None
BELL	Model 206/Accessory	206-040-004-105	Bearing	None
BELL	Model 206/Accessory	206-040-004-107	Bearing	None
BELL	Model 206/Accessory	206-040-004-109	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
BELL	Model 206/Accessory	206-040-004-111	Bearing	None
BELL	Model 206/Accessory	206-040-004-113	Bearing	None
BELL	Model 206/Accessory	206-040-004-115	Bearing	None
BELL	Model 206/Accessory	206-040-036-001	Bearing	None
BELL	Model 206/Accessory	206-040-400-003	Bearing	None
BELL	Model 206/Accessory	206-040-400-005	Bearing	None
BELL	Model 206/Accessory	206-040-400-009	Bearing	None
BELL	Model 206/Accessory	206-040-400-011	Bearing	None
BELL	Model 206/Accessory	206-040-400-013	Bearing	None
BELL	Model 206/Accessory	206-040-400-101	Bearing	None
BELL	Model 206/Accessory	206-040-400-103	Bearing	None
BELL	Model 206/Accessory	206-040-400-105	Bearing	None
BELL	Model 206/Accessory	206-040-400-107	Bearing	None
BELL	Model 206/Accessory	206-040-400-109	Bearing	None
BELL	Model 206/Accessory	206-040-402-003	Bearing	None
BELL	Model 206/Accessory	206-040-402-101	Bearing	None
BELL	Model 206/Accessory	206-040-402-105	Bearing	None
BELL	Model 206/Accessory	206-040-402-107	Bearing	None
BELL	Model 206/Accessory	206-040-402-111	Bearing	None
BELL	Model 206/Accessory	206-040-408-001	Bearing	None
BELL	Model 206/Accessory	206-040-410-001	Bearing	None
BELL	Model 206/Accessory	206-061-001-001	Bearing	None
BELL	Model 206/Accessory	206-061-001-003	Bearing	None
BELL	Model 206/Accessory	206-061-001-005	Bearing	None
BELL	Model 206/Accessory	206-061-001-007	Bearing	None
BELL	Model 206/Accessory	206-061-001-009	Bearing	None
BELL	Model 206/Accessory	206-061-001-011	Bearing	None
BELL	Model 206/Accessory	206-061-001-013	Bearing	None
BELL	Model 206/Accessory	206-061-001-017	Bearing	None
BELL	Model 206/Accessory	206-061-001-023	Bearing	None
BELL	Model 206/Accessory	206-061-001-025	Bearing	None
BELL	Model 206/Accessory	206-061-001-029	Bearing	None
BELL	Model 206/Accessory	206-061-001-031	Bearing	None
BELL	Model 206/Accessory	206-061-001-033	Bearing	None
BELL	Model 206/Accessory	206-061-001-035	Bearing	None
BELL	Model 206/Accessory	206-061-001-037	Bearing	None
BELL	Model 206/Accessory	206-061-001-039	Bearing	None
BELL	Model 206/Accessory	206-061-001-041	Bearing	None
BELL	Model 206/Accessory	206-061-001-043	Bearing	None
BELL	Model 206/Accessory	206-061-001-101	Bearing	None
BELL	Model 206/Accessory	206-061-001-103	Bearing	None
BELL	Model 206/Accessory	206-061-001-109	Bearing	None
BELL	Model 206/Accessory	206-063-001-005	Bearing	None
BELL	Model 206/Accessory	206-064-002-001	Bearing	None
BELL	Model 206/Accessory	206-064-002-103	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
BELL	Model 206/Accessory	206-064-002-111	Bearing	None
BELL	Model 206/Accessory	206-064-002-115	Bearing	None
BELL	Model 206/Accessory	206-064-002-117	Bearing	None
BELL	Model 206/Accessory	206-064-002-127	Bearing	None
BELL	Model 206/Accessory	206-961-401-001	Bearing	None
BELL	Model 212/Accessory	212-040-001-015	Bearing	None
BELL	Model 212/Accessory	212-040-001-043	Bearing	None
BELL	Model 212/Accessory	212-040-001-115	Bearing	None
BELL	Model 212/Accessory	212-040-001-123	Bearing	None
BELL	Model 212/Accessory	212-040-001-135	Bearing	None
BELL	Model 212/Accessory	212-040-001-137	Bearing	None
BELL	Model 212/Accessory	212-040-001-141	Bearing	None
BELL	Model 212/Accessory	212-040-001-149	Bearing	None
BELL	Model 212/Accessory	212-040-001-153	Bearing	None
BELL	Model 212/Accessory	212-040-001-165	Bearing	None
BELL	Model 212/Accessory	212-040-001-169	Bearing	None
BELL	Model 212/Accessory	212-040-001-177	Bearing	None
BELL	Model 212/Accessory	212-040-001-179	Bearing	None
BELL	Model 212/Accessory	212-040-001-191	Bearing	None
BELL	Model 212/Accessory	212-040-001-219	Bearing	None
BELL	Model 212/Accessory	212-040-003-007	Bearing	None
BELL	Model 212/Accessory	212-040-003-009	Bearing	None
BELL	Model 212/Accessory	212-040-003-011	Bearing	None
BELL	Model 212/Accessory	212-040-003-015	Bearing	None
BELL	Model 212/Accessory	212-040-003-017	Bearing	None
BELL	Model 212/Accessory	212-040-003-023	Bearing	None
BELL	Model 212/Accessory	212-040-004-003	Bearing	None
BELL	Model 212/Accessory	212-040-004-005	Bearing	None
BELL	Model 212/Accessory	212-040-004-009	Bearing	None
BELL	Model 212/Accessory	212-040-004-011	Bearing	None
BELL	Model 212/Accessory	212-040-004-103	Bearing	None
BELL	Model 212/Accessory	212-040-004-105	Bearing	None
BELL	Model 212/Accessory	212-062-005-001	Bearing	None
BELL	Model 212/Accessory	212-062-005-003	Bearing	None
BELL	Model 212/Accessory	212-062-005-005	Bearing	None
BELL	Model 212/Accessory	212-062-005-103	Bearing	None
BELL	Model 212/Accessory	212-062-005-105	Bearing	None
BELL	Model 212/Accessory	212-062-005-107	Bearing	None
BELL	Model 212/Accessory	212-062-005-109	Bearing	None
BELL	Model 212/Accessory	212-062-005-111	Bearing	None
BELL	Model 212/Accessory	212-062-005-113	Bearing	None
BELL	Model 212/Accessory	212-062-005-117	Bearing	None
BELL	Model 212/Accessory	212-062-005-119	Bearing	None
BELL	Model 212/Accessory	212-062-005-125	Bearing	None
BELL	Model 212/Accessory	212-062-005-131	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
BELL	Model 212/Accessory	212-062-005-137	Bearing	None
BELL	Model 212/Accessory	212-062-005-139	Bearing	None
BELL	Model 222/Accessory	222-040-003-003	Bearing	None
BELL	Model 222/Accessory	222-040-003-103	Bearing	None
BELL	Model 222/Accessory	222-040-003-109	Bearing	None
BELL	Model 222/Accessory	222-040-003-111	Bearing	None
BELL	Model 222/Accessory	222-040-003-119	Bearing	None
BELL	Model 222/Accessory	222-040-022-107	Bearing	None
BELL	Model 222/Accessory	222-040-022-108	Bearing	None
BELL	Model 222/Accessory	222-040-022-111	Bearing	None
BELL	Model 222/Accessory	222-040-022-112	Bearing	None
BELL	Model 222/Accessory	222-040-023-003	Bearing	None
BELL	Model 222/Accessory	222-040-023-101	Bearing	None
BELL	Model 222/Accessory	222-040-027-101	Bearing	None
BELL	Model 222/Accessory	222-040-027-102	Bearing	None
BELL	Model 222/Accessory	222-040-027-103	Bearing	None
BELL	Model 222/Accessory	222-040-027-104	Bearing	None
BELL	Model 222/Accessory	222-040-027-105	Bearing	None
BELL	Model 222/Accessory	222-040-027-106	Bearing	None
BELL	Model 222/Accessory	222-040-027-107	Bearing	None
BELL	Model 222/Accessory	222-040-027-108	Bearing	None
BELL	Model 222/Accessory	222-042-001-007	Bearing	None
BELL	Model 222/Accessory	222-042-001-101	Bearing	None
BELL	Model 222/Accessory	222-042-001-103	Bearing	None
BELL	Model 222/Accessory	222-060-059-101	Bearing	None
BELL	Model 222/Accessory	222-060-060-101	Bearing	None
BELL	Model 222/Accessory	222-060-060-105	Bearing	None
BELL	Model 230/Accessory	230-160-001-103	Bearing	None
BELL	Model 230/Accessory	230-160-001-104	Bearing	None
BELL	Model 407/Accessory	407-040-001-101	Bearing	None
BELL	Model 407/Accessory	407-040-001-103	Bearing	None
BELL	Model 407/Accessory	407-040-001-105	Bearing	None
BELL	Model 407/Accessory	407-040-001-107	Bearing	None
BELL	Model 407/Accessory	407-040-001-109	Bearing	None
BELL	Model 407/Accessory	407-040-006-103	Bearing	None
BELL	Model 407/Accessory	407-040-006-107	Bearing	None
BELL	Model 407/Accessory	407-040-006-111	Bearing	None
BELL	Model 407/Accessory	407-040-006-115	Bearing	None
BELL	Model 407/Accessory	407-040-006-123	Bearing	None
BELL	Model 407/Accessory	407-040-006-127	Bearing	None
BELL	Model 407/Accessory	407-040-007-103	Bearing	None
BELL	Model 412/Accessory	412-040-002-103	Bearing	None
BELL	Model 412/Accessory	412-040-002-109	Bearing	None
BELL	Model 412/Accessory	412-040-002-113	Bearing	None
BELL	Model 412/Accessory	412-040-002-117	Bearing	None

# AEROBEARINGS

## CAPABILITY LIST

OEM	Engine / Model	Part Number	Part Name	Limitation
BELL	Model 412/Accessory	412-040-004-103	Bearing	None
BELL	Model 412/Accessory	412-040-004-109	Bearing	None
BELL	Model 412/Accessory	412-040-004-127	Bearing	None
BELL	Model 412/Accessory	412-040-004-143	Bearing	None
BELL	Model 412/Accessory	412-040-006-101	Bearing	None
BELL	Model 412/Accessory	412-040-006-105	Bearing	None
BELL	Model 427/Accessory	427-040-006-107	Bearing	None
BELL	Model 427/Accessory	427-040-006-111	Bearing	None
BELL	Model 427/Accessory	427-040-006-113	Bearing	None
BELL	Model 427/Accessory	427-040-006-117	Bearing	None
BELL	Model 427/Accessory	427-040-006-119	Bearing	None
BELL	Model 427/Accessory	427-042-400-105	Bearing	None
BELL	Model 427/Accessory	427-060-101-103	Bearing	None
BELL	Model 427/Accessory	427-060-101-105	Bearing	None
BELL	Model 427/Accessory	427-140-001-101	Bearing	None
BELL	Model 430/Accessory	430-040-003-109	Bearing	None
BELL	Model 430/Accessory	430-040-003-113	Bearing	None
BELL	Model 430/Accessory	430-040-003-117	Bearing	None
BELL	Model 430/Accessory	430-160-001-103	Bearing	None
BELL	Model 430/Accessory	430-160-001-104	Bearing	None